

INSTRUCTION MANUAL

AC Trip Unit
Manual v1.00

AC-PRO-NW[®]



Trip Unit for Masterpact NW Breakers

URC Utility Relay Company
UTILITYRELAY.COM

10100 QUEENS WAY
CHAGRIN FALLS, OH 44023
USA
888.289.2864

Manual Revision 1.00 – Feb 2023 – Firmware version 4.01

Table of Contents

Section:	Page		Page
1.0 Introduction and Product Overview	3		
1.1 Current Protection and Functions	3	11.13 Instantaneous (I)	28
1.2 Voltage and Power Features - optional Voltage Divider Module (VDM)	3	11.14 Ground Fault (GF) Protection	28
1.3 Additional Features	3	11.15 Programmable Relay Outputs	28
2.0 Standards	4	11.15.1 Alarm	28
3.0 Trip Unit Power	4	11.15.2 Zone Block Relay Operation	28
3.1 Current Transformer (CT) Power	4	11.16 High Current Alarm	28
3.2 Battery Power	4	11.17 QUICK-TRIP® Instantaneous (QT-I)	28
3.3 USB Power	4	11.18 QUICK-TRIP Ground Fault (QT-GF)	28
3.4 24VDC Auxiliary Power	4	11.19 Neutral Protection (NP) Settings	29
3.5 Voltage Divider Module (VDM) Power	4	11.20 Phase Current Unbalance (U/B)	29
4.0 AC-PRO-NW® Views and Images	5	11.21 Undervoltage (UV)	29
5.0 External Connections	9	11.21.1 Undervoltage	29
5.1 CT Wiring connection	10	11.22 Overvoltage (OV)	29
5.1.1 Ground Fault Wiring Configurations	10	11.23 Phase Loss / Reverse (Φ-LOSS)	29
5.2 Actuator connection	10	11.24 Reverse Power	30
5.3 Breaker limit switch connection	10	11.25 Sluggish Breaker Setting	30
5.4 Test Set connection	10	11.26 Alarm Settings	30
5.5 Auxiliary Connections	11	11.27 Close Breaker Output Setting	30
5.5.1 24VDC Auxiliary power input	11	11.28 Limit Switch Type Setting	30
5.5.2 Local Quick-Trip switch input	11	11.29 Date/Time Format	30
5.5.3 RS-485 Communications	11	11.30 Communication Settings	30
5.5.4 Remote Quick-Trip switch (input)	11	11.31 Saving Settings	31
5.5.5 Remote Quick-Trip indication (output)	11	11.32 Settings Verification	31
5.5.6 Shunt Close (output)	11	11.33 Settings Review	31
5.5.7 Relay Outputs	11	11.34 Time & Date Settings	31
5.5.8 General Inputs	12	12.0 Trip History	31
5.5.8.1 Alarm Operation	12	13.0 Normal Operations & Readings	33
5.5.8.2 Zone Block Operation	12	14.0 Testing	34
5.6 USB Port	12	14.1 Commission the Trip Unit	34
5.7 VDM Connections	12	14.1.1 Test Mode	34
6.0 Menu Navigation	13	14.2 Long Time Trip Test	35
6.1 Power Menu	13	14.3 Short Time Trip Test	35
6.1.1 Power Demand Period	14	14.4 Instantaneous Trip Test	35
6.2 Settings Menu	16	14.5 Neutral Protection (NP) Trip Test	35
6.3 Trip History Menu	16	14.6 Ground Fault Trip Tests	35
6.4 More Menu	16	14.6.1 Residual Ground Fault Trip Test	35
6.4.1 Time and Date Setting	16	14.6.2 Ground Return Fault Trip Test	35
6.4.2 Utilities	16	14.7 QT-GF Trip Test	35
6.4.2.1 Alarms	16	14.8 CT Phasing Test for GF	35
6.4.2.2 Battery Test and Status	16	14.9 QT-I Trip Test	36
6.4.2.3 Ground Fault Trip Test	16	14.10 Phase Current Unbalance Trip Test	36
6.4.3 Breaker Cycle Counter	16	14.11 Undervoltage (UV) Test	37
6.4.4 Scheduled Service Reminder	16	14.12 Overvoltage (OV) Test	37
7.0 QUICK-TRIP® (Arc Flash hazard reduction / ERMS)	18	14.13 Phase Loss / Reverse Test	38
7.1 QUICK-TRIP® Basics & Operation	18	14.14 Reverse Power Test	38
7.2 Local QT-Switch	19	15.0 Secondary Injection Testing	38
7.3 Remote QUICK-TRIP® Switch	19	15.1 Secondary Injection Test Set	38
7.4 QUICK-TRIP® Remote Indication	19	15.2 Standard Relay Test Set	38
7.5 QUICK-TRIP® ON / OFF Control	19	15.3 LT Delay Testing Chart	39
8.0 Voltage Divider Module (VDM) (optional)	20	15.4 Neutral Protection Testing Chart	40
8.1 Voltage-Based Protection	20	16.0 Ratings & Physical Information	40
9.0 SAFE-T-TRIP™ (optional)	21	17.0 Warranty	41
10.0 Sluggish Breaker™ Detection	21	18.0 Time-Current Curves (TCC)	41
11.0 Commissioning the AC-PRO-NW®	22	18.1 Long Time (LT) Trip Time	41
11.1 Powering-Up the Trip Unit for Commissioning	22	18.2 Short Time (ST) Trip Time	41
11.1.1 Internal Battery	22	18.3 Ground Fault (GF) Trip Time	42
11.1.2 USB Power	22	18.4 Phase Current U/B Trip Time	44
11.1.3 24VDC Auxiliary Power	22	18.5 Neutral Protection (NP) Trip Times	44
11.2 Un-commissioned Screens	22	18.6 Current Metering Accuracy	48
11.3 Entering & Changing Settings locally	23	19.0 Voltage & Power Calculations	48
11.4 Security Code	27	20.0 Error and Alarms	48
11.5 CT Rating	27	20.1 Internal Error	48
11.6 Power Flow Direction	27	20.2 Actuator Open Circuit	48
11.7 Frequency	27	20.3 CT Open Circuit	48
11.8 CT Auto-Polarity Correction	27	20.4 Alarm Screens	48
11.9 CT Open circuit detection	27	20.5 Un-Calibrated	48
11.10 Long Time (LT)	27	21.0 Battery	49
11.11 Thermal Memory	27	21.1 Checking the Battery Voltage	49
11.12 Short-Time (ST)	27	21.2 Battery Replacement	49
		22.0 InfoPro-AC™ Software Application	49
		22.1 Firmware Versions and Updates	50
		23.0 RS-485 Communications	54

23.1 RS-485 Communications Introduction.....	54	23.5 Modbus Registers.....	55
23.2 Communications Components	54	24.0 Breaker Trip and Close Control	58
23.3 Communications Wiring.....	54	25.0 Wireless Communications	59
23.4 System Components & Computer Hardware ..	54		
23.4.1 Ethernet.....	54		
23.4.2 Smart 1-Line.....	54		

Utility Relay Company
 10100 Queens Way
 Chagrin Falls, OH 44023
www.utilityrelay.com
 Phone 888-289-2864



For latest version, visit:

http://www.utilityrelay.com/Side_Bar/Instruction_Manuals.html

List of Figures

Figure	Page
Figure 4.1: Front and Rear View Drawing	5
Figure 4.2: AC-PRO-NW Front View Photo	6
Figure 4.3: AC-PRO-NW Top (Auxiliary) View	7
Figure 4.4: AC-PRO-NW Rear View Connections	8
Figure 6.1: Main Screen.....	13
Figure 6.2: Power Menu Screens.....	14
Figure 6.3: Typical AC-PRO-NW Menu Navigation Map - Simple View	15
Figure 6.4: Settings Menu first screen.....	16
Figure 6.5: MORE Menu.....	17
Figure 7.1: QUICK-TRIP System and Connections.....	18
Figure 7.2: Local QT-Switch Mounting	19
Figure 7.3: Front Panel QUICK-TRIP ON/OFF Control.....	19
Figure 7.4: Breaker Control Window (InfoPro-AC or Smart 1-Line)	20
Figure 9.1: SAFE-T-TRIP	21
Figure 9.2: SAFE-T-TRIP in case	21
Figure 10.1: Sluggish Breaker Screen	21
Figure 11.1: Un-commissioned Screens.....	22
Figure 11.2: Change Settings Menu - Part 1	23
Figure 11.3: Change Settings Menu - Part 2	24
Figure 11.4: Change Settings Menu - Part 3.....	25
Figure 11.5: Change Settings Menu-Part 4.....	26
Figure 11.6: Settings Screen - Review Button	31
Figure 12.1: Trip History Menu	32
Figure 13.1: Main ("Readings") Screen	33
Figure 13.2: Power and Energy screen.....	33
Figure 14.1: Test Mode Screens	34
Figure 14.2: Phase A & B, CT Polarity Test.....	36
Figure 14.3: Phase B & C, CT Polarity Test.....	36
Figure 14.4: Phase Current Unbalance Test.....	36
Figure 14.5: Voltage Test	37
Figure 15.1: B-292 Secondary Injection Test Set.....	38
Figure 18.1: Overload TCC	43
Figure 18.2: Ground Fault (GF) TCC	45
Figure 18.3: QUICK-TRIP Ground Fault and QUICK-TRIP Instantaneous TCCs	46
Figure 18.4: Phase Current Unbalance TCC.....	47
Figure 20.1: Internal Error Screen	48
Figure 20.2: Actuator Open screen	48
Figure 20.3: Alarm Screen.....	48
Figure 20.4: Clear Alarms Screen.....	48
Figure 20.5: Un-Calibrated Screen	48
Figure 21.1: Battery Cover	49
Figure 22.1: InfoPro-AC Readings Tab	51
Figure 22.2: InfoPro-AC Waveform Tab	51
Figure 22.3: InfoPro-AC Trip History Tab	52
Figure 22.4: InfoPro-AC Settings Tab	52
Figure 22.5: InfoPro-AC TCC / Tests Tab.....	53
Figure 22.6: InfoPro-AC Breaker Control Window	53
Figure 23.1: Typical Communications Configuration Example.....	56
Figure 23.2: Smart 1-Line Communication Solution	56
Figure 23.3: Smart 1-Line / Run Mode Example.....	57
Figure 23.4: Smart 1-Line / Breaker Status and Alarms Screen.....	57

1.0 Introduction and Product Overview

The AC-PRO-NW® is a state of the art, micro-controller based trip unit for use on three phase, 600 Volt class, AC circuit breakers on 50 Hertz or 60 Hertz systems. The AC-PRO-NW features a 128 x 64 Multi-line, Organic Light Emitting Diode (OLED) Display, smart buttons, and LEDs.

The standard AC-PRO-NW provides:

- Overload and fault protection
- RS485 and Wireless communications
- QUICK-TRIP® arc flash hazard reduction
- Patented Sluggish Breaker® detection
- Time stamped trip history with waveform capture
- InfoPro-AC™ software interface
- Ready for the SAFE-T-TRIP® hand-held remote trip device
- And many other features

Additionally, with the optional Voltage Divider Module (VDM™), the AC-PRO-NW can provide advanced voltage, power and energy features.

1.1 Current Protection and Functions

The AC-PRO-NW includes the following Current-based features:

- Long Time (LT)
- Short Time (ST)
- Instantaneous (I)
- Ground Fault (GF)
- Thermal Memory (for LT, ST, & GF)
- Neutral Protection (NLSI)
- Phase Current Unbalance (U/B %)
- QUICK-TRIP Instantaneous (QT-I)
- QUICK-TRIP Ground Fault (QT-GF)
- Current Metering
- Overload (Long Time pickup) Alarm
- Instantaneous Override (I-OVRD)
(factory setting – normally enabled)
- Instantaneous on Close (I-CLOS)
(factory setting – normally enabled)
- CT Polarity Correction
- High Current alarm

The AC-PRO-NW measures the true RMS current through each of the breaker's three poles.

The QUICK-TRIP Instantaneous and QUICK-TRIP Ground Fault protective settings are available to minimize downstream Arc Flash Hazard.

1.2 Voltage and Power Features - optional Voltage Divider Module (VDM)

The AC-PRO-NW can be provided with an optional Voltage Divider Module (VDM) internal to the trip unit.

When factory-configured with the VDM, the AC-PRO-NW offers the following Voltage-based features:

- Rated for up to 600V three-phase systems
- Voltage metering and protection: Line-to-Line
- Under-Voltage trip & alarm
- Over-Voltage trip & alarm
- Phase Loss/Reversal trip & alarm
- Reverse Power trip & alarm
- Power metering:
KW, KVA, KWHr, KVAHr, Power Factor, KW Demand, KVA Demand
- VDM provides trip unit power when it is connected to energized bus. The existing Masterpact NW breaker voltage connections are normally on the bottom terminals (load side) of the breaker.

1.3 Additional Features

In addition, the AC-PRO-NW also features the following: (features are standard for all AC-PRO-NW trip units unless noted otherwise)

- Programmable relay outputs – can be used for alarms or or Zone-Block signal
- Self-Test
- Front USB port for data upload and download, SAFE-T-TRIP remote trip device, auxiliary power and firmware updates
- OLED multi-line display
- RS-485 Modbus RTU communications
- Wireless communications
- Versatile user settings provide more flexibility than the original AC-PRO:
 - 50 Hz or 60 Hz operation
 - Ground Fault type can be set to "Residual" or "Ground Return" depending on the CT location & Ground Fault scheme.
- Waveform capture
- Sluggish Breaker Detection™, Breaker Cycle Counter
- Time-stamping of Trip events
- Scheduled Service Reminder
- Output for closing E/O breaker
- Delayed manual trip and close (close requires E/O)

The trip unit stores the trip history data for the last 8 trip events and the trip log data in a non-volatile FRAM memory for later recall. All the settings are stored in non-volatile memory. Battery backup is not required.

The trip unit basic functions do not require external power to operate. Power is derived from the current transformers (CTs). An internal battery provides power to review and change protection settings when CT power is not available.

The AC-PRO-NW trip unit is manufactured under multiple patents. See the link below for additional information:
<http://www.utilityrelay.com/patents.html>

NOTE: this manual is written based on version 4.01 firmware. See the following for details:
http://www.utilityrelay.com/Side_Bar/Firmware_versions.html

2.0 Standards

The AC-PRO-NW has the CE Mark.

AC-PRO-NW was tested by an independent laboratory and found in compliance with the following standards:

IEEE C37.90.1, Surge Withstand
 IEEE C37.90.2, RF Susceptibility
 IEC 61000-4-3, RF Immunity
 IEC 61000-4-4, Fast Transient
 IEC 61000-4-5, Surge Immunity
 IEC 61000-4-2, Electrostatic Discharge Immunity
 EN 55011 / CISPR11 / FCC part 15, Subpart B,
 Radiated & Conducted Emissions
 IEC 61000-4-6, Conducted RF Immunity
 IEC 61000-4-18, Damped Oscillatory Immunity

AC-PRO-NW was designed and tested per IEEE C37.59.

3.0 Trip Unit Power

The AC-PRO-NW can be powered in 5 different ways: CTs, internal battery, USB port, 24VDC auxiliary, or by the internal optional Voltage Divider Module (VDM).

The AC-PRO-NW is normally powered from the breaker phase CT's if at least one phase current is above the CT power-up threshold. If the current is not high enough to power the trip unit, the trip unit will power down. If the unit is powered down and a fault occurs requiring rapid response, the high current of the fault provides CT power and the trip unit performs as published in the Time Current Curves.

If the trip unit is connected to a Voltage Divider Module (VDM), USB, or 24VDC auxiliary power, these sources provide constant power.

During normal operation (in service), if the trip unit is powered by current or voltage and no errors are present, the OK LED should be blinking. If current is too low or if voltage (via VDM) is not present, pressing the "DISPLAY" Push button will temporarily power up the trip unit and display using the internal battery. The OK LED should then be on.

3.1 Current Transformer (CT) Power

The AC-PRO-NW derives both the signal and power from the breaker phase CTs. The trip unit will power-up with less than 6% of the rated CT tap current through a single CT.

3.2 Battery Power

A 3-Volt, 850 mAh, CR2, long life Lithium battery is used in the trip unit. There are no restrictions on transport and no special methods of disposal required with this battery.

The AC-PRO-NW design uses the battery for the following functions / features:

- 1) Allows the user to commission (program) the trip unit without using the auxiliary power pack.
- 2) Allows the user to recall last trip data even if the breaker is open and without using the auxiliary power.
- 3) Maintains the internal clock for accurate time and date stamping for trip history and on-demand waveforms.

Press the "DISPLAY" push button to turn the trip unit on under battery power.

When on battery power, the trip unit will automatically turn off 60 seconds after the last button is pushed to conserve battery energy.

**** NOTE ****

The battery is NOT involved in the protective functions of the trip unit. The trip unit will provide protection even if the battery is removed.

The battery is NOT required for the trip unit to maintain any of its memory including the user programmed pick-up and delay settings and the last trip data.

If the battery voltage is low, the internal date/time clock will not be correct.

See Section 21.0 for battery data and instructions on replacing the battery.

3.3 USB Power

The AC-PRO-NW® is equipped with a mini-USB port on the face of the trip unit and it can be used to power the trip unit display with the USB 5Vdc supplied by a computer, USB wall-pack, etc.

Note: USB power is NOT sufficient for powering AC-PRO-NW when using a relay (secondary injection) test set.

3.4 24VDC Auxiliary Power

The AC-PRO-NW® can be powered by 24VDC Auxiliary power. This power source is optional and is not required for LSIG protection features. 24VDC power is required for the following features: Relay outputs, Shunt Close, General inputs, Remote Quick-Trip.

Many NW breakers/cubicles are already equipped with 24VDC Aux power.

24VDC Auxiliary power requirements:

Voltage: 23-28VDC with correct polarity

Power supply sizing: 3 watts minimum per AC-PRO-NW

Protection: protect each AC-PRO-NW with 1A fuses

Use a minimum of 1 power supply per lineup.

3.5 Voltage Divider Module (VDM) Power

The AC-PRO-NW® trip unit is available with an optional internal Voltage Divider Module (VDM). The VDM provides breaker 3-Phase voltage used for power information and also provides power for the trip unit independently from the CTs. See Section 8.0 for more information on the Voltage Divider Module (VDM).

4.0 AC-PRO-NW® Views and Images




Figure 4.1: Front and Rear View Drawing




Figure 4.2: AC-PRO-NW Front View Photo

- A. OLED Display**
The display is normally off. Pushing the “DISPLAY” button (B) turns on the display. Refer to Section 6.0 for menu navigation.
- B. DISPLAY Push Button**
Pushing the “DISPLAY” button will turn on the display. If no buttons are pushed for 60 seconds, the display will turn off. When the display is at the main screen, pressing the button will change the smart button labels, allowing access to additional menus/functions. When the display is ON, and the button is held for 3 seconds, the display will return to the main screen.
- C. “Smart” Push Buttons**
These four (4) push buttons perform the functions indicated on the bottom of the OLED display. These buttons are used for all menu navigation.
- D. Red PICK-UP LED (red)**
This LED will illuminate if the current exceeds the LT pick-up setting.
- E. Wireless LED (blue)**
This LED will illuminate (blink) if the wireless radio is enabled.
- F. Test Port (shown w/ cover on)**
This port is for secondary injection testing with URC B-292 Test set.
- G. Top Aux connector (see next page)**
- H. AC-PRO-NW Serial Number**
- I. Green OK (Self-Test) LED**
When the trip unit is powered up, this LED is on and blinking unless a problem is detected. If the trip unit is not powered up, the OK LED will not be on. If the “DISPLAY” button is pressed, the OK LED should come on, unless a problem is detected. See Section 11.1 for Trip Unit Power and Section 20.0 for Errors.
- J. Battery Cover / Holder**
To replace the battery, remove the screws and slide battery cover out, remove the old battery and insert a new CR2, 3-Volt Lithium battery. Replace the battery cover/holder and screws. See Section 21.0.
- K. Mini-USB Port (shown with cover)**
The electrically isolated mini-USB port is available for connection to a laptop/ personal computer for uploading & downloading of settings, information, and firmware; SAFE-T-TRIP remote trip device operation; or USB wall pack for auxiliary power.
- L. RS-485 LED (green)**
The communications active LED illuminates when the trip unit is communicating information via RS-485 Communications.
- M. Quick-Trip LED (red)**
This LED will illuminate when the device is in Quick-Trip mode (Arc Flash hazard reduction / ERMS).




Figure 4.3: AC-PRO-NW Top (Auxiliary) View

Top Aux Connector:

24V(+) Aux Power
24V(-) Aux Power
Local QT Switch
RS-485 Comm (-)
RS-485 Comm (+)
space
Remote QT in (+)
Remote QT in (-)
Remote QT out (+)
Remote QT out (-)




Figure 4.4: AC-PRO-NW Rear View Connections

1. Rear Auxiliary Connector

- a. Shunt Close (+)
- b. Shunt Close (-)
- c. space
- d. General Input 1
- e. General Input 2
- f. Relay Output 2
- g. Relay +24V Com
- h. Relay Output 1

2. Wireless Communication Switch

“ON”= unit is capable of wireless comm, if enabled using front panel

“OFF = wireless circuitry is disabled and the user cannot enable the feature using the front panel


3. CT wiring connector

- (see label for polarity dots)
- Neutral
 - Phase C
 - Phase B
 - Phase A

4. Actuator and Limit Switch pin connections (mates automatically when trip unit is attached to existing mount)


5. VDM (Voltage Divider Module) Pin connections (mates automatically when trip unit is attached to existing mount). These pins are present on AC-PRO-NW equipped with the optional (internal) VDM.

5.0 External Connections



TOP AUX CONNECTOR (FRONT VIEW)

- 24V+ Aux power
- Aux power -
- Local QT switch
- RS-485 Comm -
- RS-485 Comm +
- space
- Remote QT in +
- Remote QT in -
- Remote QT out +
- Remote QT out -



REAR AUX CONNECTOR

- Shunt Close +
- Shunt Close -
- space
- General Input 1
- General Input 2
- Relay Output 2
- Relay +24V Com
- Relay Output 1




Figure 5.1: AC-PRO-NW Typical Connections and Wiring




Figure 5.2: AC-PRO-NW Typical Ground Return Wiring Diagram

5.1 CT Wiring connection

The CT inputs are on an 8-pin connector on the back of the trip unit. The connector includes wires for the Phase A CT, Phase B CT, Phase C CT, and optional Neutral CT.

A neutral CT wiring harness is provided as part of the neutral CT installation kit. The neutral CT kit is required for units applied to 4-wire systems where Ground Fault protection is desired or required. The ground fault function on a 3-wire system does not require a neutral CT. Additionally, this connection method allows Neutral Overload Protection to be implemented.

5.1.1 Ground Fault Wiring Configurations

The AC-PRO-NW is compatible with multiple types of existing Ground Fault protection schemes.

Figure 5. shows a residual Ground Fault wiring diagram. For this configuration, the AC-PRO-NW calculates the residual Ground Fault current. If the system is a 4-wire (3-phase + neutral), the neutral CT must be provided if Ground Fault protection is desired.

Figure 5. shows a ground return Ground Fault wiring diagram. For this configuration, the AC-PRO-NW directly measures the Ground Return current on the neutral current input. An Aux CT can be supplied for current isolation in the ground circuit. This configuration only applies to 4-wire systems where Ground Fault protection is required. Neutral protection cannot be implemented if the Ground Fault type is Ground Return.

See Section 11.14 for Ground Fault settings.

Contact Utility Relay Company if your Ground Fault Protection scheme is different than the typical schemes shown above.

5.2 Actuator connection

The existing breaker trip actuator is connected to the AC-PRO-NW automatically (via pins) when the trip unit is mounted to the breaker.

5.3 Breaker limit switch connection

The existing breaker limit switch is connected to the AC-PRO-NW automatically (via pins) when the trip unit is mounted to the breaker.

This limit switch is used for the following:

- Determine breaker position for indication, control logic, and cycle counting.
- Instantaneous-on-close protection: this protects the breaker from closing in on large faults.
- Sluggish breaker detection: measurement of the breaker mechanism time.

5.4 Test Set connection

The Test port on the front of the AC-PRO-NW is exclusively for use with the URC B-292 Secondary Injection Test set and CA-7-114-NW cable.



The Test port is for temporary use and should only be used when the breaker is NOT in service. When the breaker is in service, the test port cover should be in place.

The Test port includes current inputs, a trip signal output, and auxiliary power.

5.5 Auxiliary Connections

The AC-PRO-NW includes two Auxiliary terminal blocks.

The top Auxiliary terminal block is shown in Figure 4.3. It allows for connection of 24VDC Auxiliary power, Local Quick-Trip switch, RS-485 Communications, Remote Quick-Trip switch (input), and Remote Quick-Trip indication (output).

The rear Auxiliary terminal block is shown in Figure 4.4. It allows for connection of Shunt Close (output), Relay outputs, and General inputs.

Wiring for the auxiliary terminal block is furnished in AC-PRO-NW retrofit kits.

The auxiliary terminal block features set-screw connections and accepts #14 AWG - #28 AWG conductors.

5.5.1 24VDC Auxiliary power input

The top aux connector can accept 24VDC Auxiliary power. See Section 3.4 for additional information.

5.5.2 Local Quick-Trip switch input

For applications where a local external pad-lockable Quick-Trip switch is required, a local Quick-Trip (ERMS) switch can be connected to the top aux connector. This input is exclusively for connection to a local, cubicle door-mounted pad-lockable switch provided by URC.

For more information about Quick-Trip Arc Flash Hazard Reduction, see Section 7.0.

5.5.3 RS-485 Communications

The top aux connector can be connected to a 2-wire RS-485 network for Modbus communications. Refer to the Communications Section of this manual for additional information.

5.5.4 Remote Quick-Trip switch (input)

For applications where a Remote external Quick-Trip switch is required, a Remote Quick-Trip (ERMS) switch can be connected to the top aux connector. This input is exclusively for a remote switch with an external 24VDC, 120VAC, or 125VDC source.

The AC-PRO-NW must be supplied with 24VDC Aux power for the Remote Quick-Trip feature to function.

For more information about Quick-Trip Arc Flash Hazard Reduction, see Section 7.0.

5.5.5 Remote Quick-Trip indication (output)

For applications where Remote Quick-Trip indication (for example and LED or input to a system) is required, the related wiring can be connected to the top aux connector. This output is exclusively for a remote switch with an external 24VDC, 120VAC, or 125VDC source. The output is rated 100mA.

The AC-PRO-NW must be supplied with 24VDC Aux power for the Remote Quick-Trip feature to function.

For more information about Quick-Trip Arc Flash Hazard Reduction, see Section 7.0.

5.5.6 Shunt Close (output)

For breakers that are equipped with an OEM "XF" close coil, the AC-PRO-NW is capable of initiating a close signal. When the command is issued, this output "closes" for 200ms.

The AC-PRO-NW must be supplied with 24VDC Aux power for this feature. The output ratings are as follows:

Voltage: 250VDC max, 240VAC max

Momentary Current: 4A max

5.5.7 Relay Outputs

The AC-PRO-NW is equipped with two (2) programmable "relay" outputs. The trip unit includes a common +24V output that can be used with these outputs.

The AC-PRO-NW must be supplied with 24VDC Aux power for the relay outputs to function. The output ratings are as follows: Voltage: 24VDC, Current: 20mA

5.5.8 General Inputs

The two (2) general (digital) inputs are intended for future features and presently have limited functionality. The AC-PRO-NW +24V common output can be wired through a switch or contact. If 24VDC is applied to an input, the input status "ON" is displayed on a screen in the "More" menu.

5.5.8.1 Alarm Operation

If used for Alarms, all related alarms and errors result in a specific message on the display screen. The relay can be configured to operate for any combination of the conditions listed in Table 5-A. The reset method for each alarm condition is also listed in the Table below.

Alarm Condition	Reset Method
Trip	Manual reset
Internal Error	Auto reset
Actuator Open Error	Auto reset
Sluggish Breaker	Manual reset
UnderVoltage*	Manual reset
OverVoltage*	Manual reset
LT Pickup	Auto reset
Phase Current Unbalance	Manual reset
Phase Loss/Rev *	Auto reset
Reverse Power*	Manual reset
Ground Fault	Manual reset
Service Reminder	Manual reset
High Current	Auto reset
Reversed CT	Auto reset

* - requires VDM / "Manual" = reset by user
 "Auto" = trip unit resets when condition no longer present

Table 5-A: Alarm Configuration

The alarms listed as "Manual Reset" can be reset at the alarm screens. Additionally, the alarms can be manually reset using the "More" menu. See Section 20.0 for the alarm screens and Section 20.3 for the manual alarm reset screen.

5.5.8.2 Zone Block Operation

- When the Programmable Relay Function is set to "Zone Block" (See Section 11.15.2), the relay contact will operate rapidly when current exceeds the respective pickup setting.
- The user must set the "Programmable Relay Function" setting to "Zone Block".
- The user must then set the "Zone Block Relay Contact Operation" setting to operate for the "ST Pickup", and/or "Inst (Instantaneous) Pickup", and/or "GF Pickup" condition(s).
- Typical Zone Block Relay Contact operation for Instantaneous Pickup condition (**24VDC Aux power required**). See note 6a below):
 - Once AC-PRO-NW detects an Instantaneous overcurrent event, it will commit to Instantaneously trip the breaker and it will operate the Zone Block relay contact.

- The Zone Block relay contact will operate ~6-10ms after the start of the Instantaneous overcurrent event.
 - The Zone Block relay contact will remain in the operated position while the current is greater than the pickup setting, plus at least an additional ~30-60ms.
- Typical Zone Block Relay Contact operation for Short Time (ST) or Ground Fault Pickup (GF) condition (**24VDC Aux power required**). See note 6a below):
 - Once AC-PRO-NW detects an ST or GF overcurrent event, it will begin timing for that trip function, and it will operate the Zone Block relay contact.
 - The Zone Block relay contact will operate ~6-16ms after the start of a ST overcurrent event, or ~16-40ms after the start of a GF overcurrent event.
 - The Zone Block relay contact will remain in the operated position while the current is greater than the pickup setting, plus at least an additional ~30-60ms.
 - Zone Block (customer) requirements:
 - Supply 24VDC auxiliary power to each AC-PRO-NW. (**required for rapid operation and for automatic reset of relay contact**). (allow 3 watts per AC-PRO-NW)
 - Supply wiring and voltage for/from upstream relay digital input. (AC-PRO-NW Zone block contact is a dry contact).

See Section 11.15.2 for additional information.

5.6 USB Port

The USB Port (mini-USB) on the front of the trip unit is electrically isolated and available for the following connection options:

- Laptop or personal computer with InfoPro-AC software: (See Section 22.0 for more information.)
- SAFE-T-TRIP remote trip device.

A rubber cover is provided for the USB port.

**** IMPORTANT ****

Replace the USB port cover after use.

5.7 VDM Connections

If the AC-PRO-NW is purchased with an internal VDM (Voltage Divider Module), it will be capable of voltage, power, and energy features. The existing breaker voltage connections to the AC-PRO-NW are automatically made (via pins) when the trip unit is mounted to the breaker. The existing voltage connections are located on the load side (lower terminals) of the breaker. Refer to Section 8.0 for additional Voltage Divider Module (VDM) information.

6.0 Menu Navigation

AC-PRO-NW settings and information can be navigated using the push buttons on the face of the trip unit. Pressing the "DISPLAY" button wakes the display up from its power saving mode. After the display is on, all menu navigation is accomplished using the screen prompts and (4) smart buttons below the display. The smart button labels appear at the bottom of the screen.

In normal operation, the main screen is the first screen displayed after waking the display up. The main screen provides actual values for Phase A, B, and C current, as well as Neutral and Ground Fault currents. For Phase currents below 10% of the CT rating, "LOW" will be displayed. Neutral and Ground Fault fields will be blanked when these currents are below 10% of the CT rating.

Additionally, if a Voltage Divider Module (VDM) is present, the main screen also displays voltages for Phase A, B, and C. The main screen also provides access to four (4) main menus via smart buttons. See the main screen example below along with list of menus and sub-menus:




Figure 6.1: Main Screen
(Optional voltage values shown)

- 1) PWR (Power Menu): This menu provides access to power values, which become available if the optional Voltage Divider Module (VDM) is connected.
- 2) SET (Settings Menu).
 - a. REV (Review Settings sub-menu): This sub-menu allows review of all user settings without the option of changing the settings.
 - b. CHNG (Change Settings sub-menu): This sub-menu allows the user to change all protection, alarm, and breaker information settings.
 - c. TEST (Test Mode): See Section 14.1.1.
- 3) HIST (Trip History Menu): This menu provides access to trip history information for up to eight (8) trips.

- 4) MORE (Trip Unit Information Menu): This menu includes serial number(s), time & date settings, battery status, URC contact info, etc.
- 5) QT (Quick-Trip) – When at the Main Screen, pressing the DISPLAY button will change the bottom labels at the bottom of the screen. This will allow access to the (QT) QUICK-TRIP® mode control. See Section 7.0 for additional information.
- 6) BT (Wireless comm) - When at the Main Screen, pressing the DISPLAY button will change the bottom labels at the bottom of the screen. This will allow access to the (BT) Wireless Communications mode control. See Section 24.0, Breaker Trip and Close Control for additional information.
- 7) CONT (Breaker Trip and Close* control) - When at the Main Screen, pressing the DISPLAY button will change the bottom labels at the bottom of the screen. This will allow access to the (CONT) Breaker control screen. See Section 25.0, Wireless Communications.

See Section 13.0 for information on values displayed on readings screens.

For reference, see the following table for common smart buttons and associated actions, which may appear depending on the specific screen.

Smart Button Label	Action
Next	Proceed to next screen or next setting
Back	Return the previous screen or previous setting
Exit	Return to the Main Screen
Up	Increase setting value or toggle to next setting value.
Down	Decrease setting value or toggle to previous setting value.
ON	Turn function or feature ON.
OFF	Turn function or feature OFF.

Table 6-A: Common Smart Button Actions

See Figure 6.2 for a simple view menu navigation map.

6.1 Power Menu

If the AC-PRO-NW is equipped with the optional Voltage Divider Module (VDM), the power menu becomes available. The power menu is accessed from the main screen by pressing the "PWR" smart button. The smart buttons allow navigation to subsequent screens, which display power information, as well as the capability of resetting energy usage values. The figure below shows the

flow of the Power Menu.




Figure 6.2: Power Menu Screens

Note: Power Menu only appears if the optional VDM is connected.

6.1.1 Power Demand Period

Choose Edit Menu key to modify the Demand Period. It can be adjusted from a 5 to 60 minute rolling window with 15 minutes being the default demand period. Kilowatt Demand (KWD) and Kilovoltamps-Demand (KVAD) are recorded with "Last" and

"Peak" values logged. Use Reset to clear the Power Demand Peak values.

See Section 13.0 for information on values displayed on the readings screens.




Figure 6.3: Typical AC-PRO-NW Menu Navigation Map - Simple View

6.2 Settings Menu

The settings menu provides the ability to review and modify settings. The first settings menu screen provides access to the following settings sub-menus by pressing the associated smart push buttons: review settings sub-menu, change settings sub-menu, and Test Mode. See the settings menu first screen in the following figure:




Figure 6.4: Settings Menu first screen

For details regarding Settings, refer to Section 11.0.

6.3 Trip History Menu

The AC-PRO-NW stores data from the last eight (8) trips. The trip history menu displays this information. The trip unit stores trip counts, types, time stamps, and currents. If a VDM is connected, voltages will also be stored in the trip history. Additionally, the breaker mechanism times for all trips are stored. Refer to Section 12.0 for details regarding trip history and navigating the trip history menu. (Use InfoPro-AC software to view current and voltage waveforms. See Section 22.0.)

6.4 More Menu

The more menu provides access to the following trip unit information and functions:

- 1) Breaker Name (use InfoPro-AC to set)
- 2) Breaker Status (requires limit switch)
- 3) Trip unit serial number.
- 4) Local display serial number (this is separately provided since the local display can be separated from the trip unit).
- 5) Trip unit firmware revision number and VDM version number (if applicable).
- 6) Local display firmware revision number.
- 7) Time and Date - Viewing and setting.
- 8) Manually reset the alarms.
- 9) Battery test and status.
- 10) Utility Relay Company contact information. (More/Next/Next/URC button)
- 11) Perform a Ground Fault Trip Test
- 12) Breaker Cycle Counter
- 13) Scheduled Service Reminder (see below)
- 14) General (digital) input status

6.4.1 Time and Date Setting

The time and date setting is accessed via the MORE menu, by pressing the MORE button at the main screen, then the time button, then the change button, as shown and noted below in Figure 6.5: MORE Menu.

The time and date setting is important, as trip events and waveform captures are time stamped.

**** IMPORTANT ****

The time and date must be set after commissioning the AC-PRO-NW or after replacing the battery to ensure the time stamps (of trips and on-demand waveforms) are recorded and are correct.

In order for the time and date to remain accurate after setting, a fresh battery must be in place.

There is no provision for daylight savings time.

6.4.2 Utilities

6.4.2.1 Alarms

See Section 5.3.1 Alarm Operation for all alarms. Use screen to Reset.

6.4.2.2 Battery Test and Status

The trip unit internal battery state can be tested and viewed using the MORE menu. Press "MORE", then press "Util", then "Batt" as shown below. "Test" displays voltage.

6.4.2.3 Ground Fault Trip Test

The trip unit can perform a Ground Fault trip test. This simulates a measured Ground Fault condition, and tests the trip unit's ability to perform a trip. Ground Fault Protection or Quick-Trip Ground Fault Protection must be turned on to perform a Ground Fault Test Trip. See Figure 6.5: MORE Menu. **Error! Reference source not found.**

6.4.3 Breaker Cycle Counter

If the Sluggish Breaker Position Indicator 52a / 52b limit switch is active (See 5.3.3), the "Breaker Cycle Counter" will log the number of operations of the breaker that occurred **while the trip unit was powered up**. Choose the DISPLAY key, More, Next (3) times. The Breaker Cycle Counter can be RESET at same menu and via InfoPro-AC. (Note: the trip unit must be powered via CTs, VDM, USB or Aux Power to log breaker operations.)

6.4.4 Scheduled Service Reminder

This feature allows the user to program a "reminder" date for breaker service. The user can also program a company name and contact info. On the reminder date, a "Service Reminder" screen will appear with the company name and contact info, if entered.




Figure 6.5: MORE Menu

7.0 QUICK-TRIP® (Arc Flash hazard reduction / ERMS)




Figure 7.1: QUICK-TRIP System and Connections

7.1 QUICK-TRIP® Basics & Operation

All AC-PRO-NW include the Quick-Trip feature for Arc Flash Hazard Reduction.

The QUICK-TRIP system is a manually controlled arc flash hazard reduction system; otherwise known as an Energy Reducing Maintenance Switch (ERMS). It can reduce trip times when turned on and allows selective coordination between circuit breakers when turned off.

If maintenance personnel must work on energized equipment, they will first turn the QUICK-TRIP system on at the upstream breaker feeding the equipment. If a fault now occurs, the upstream breaker will trip quickly based on the QUICK-TRIP settings **reducing the Arc Flash Hazard to personnel**.

When the maintenance work is finished, the QUICK-TRIP system is turned off and the original selective coordination is back in effect.

The QUICK-TRIP mode can now be controlled with physical switches or by “soft” means. It is recommended that only one or the other means is used. See Section 7.5 for additional information.

When QUICK-TRIP is **ON**, the following settings are enabled:

- QUICK-TRIP Instantaneous (QT-I)
- QUICK-TRIP Ground Faulty (QT-GF) (if QT-GF enabled in settings)

These are standard AC-PRO-NW settings. All other settings remain in effect. Refer to Section 6.2.

The “QUICK-TRIP” LED provides positive indication that the QUICK-TRIP settings are active if the LED is on. If the AC-PRO-NW is not powered up (by current, voltage (VDM), USB or 24VDC Aux.), the DISPLAY button is available. Pressing this button will “wake up” the trip unit using the AC-PRO-NW battery, and the QUICK-TRIP LED will illuminate, providing positive indication that the unit is in Quick-Trip mode.

The AC-PRO-NW offers several options for Quick-Trip control and indication. Below are some options:

Option #1: Use trip unit only. No external components or wiring.

Control: trip unit screen and buttons

Indication: trip unit LED

24VDC Aux power to trip unit: NOT required

Option 2: Use URC external local QT switch

Control: URC local external lockable switch

Indication: trip unit LED

24VDC Aux power to trip unit: NOT required

Option 3: Remote QT switch and indication

Control: Remote QT switch

Indication: Remote QT LED or Remote system input and trip unit LED

24VDC Aux power to trip unit: REQUIRED

External voltage: REQUIRED for Remote switch and indication

Option 4: Reuse existing ERMS Switch/LED or Install new QT Switch/LED

Control: QT switch/LED combo

Indication: QT switch/LED combo and trip unit LED

24VDC Aux power to trip unit: REQUIRED

External voltage: 24VDC REQUIRED

****** IMPORTANT ******

A qualified engineer must determine the QUICK-TRIP settings, calculate the incident energy levels and determine the Hazard Risk Categories (HRC).

7.2 Local QT-Switch

To install the QT-Switch:

1. Use a 22mm switch knock-out punch to make a hole in the cubicle door for the selector switch.
2. Attach the selector switch, padlock attachment and contact blocks to the cubicle door.
3. Wire the 2/C cable to AC-PRO-NW on the breaker. On drawout breakers, utilize spare secondary disconnect terminals, or use the wire harness with connector supplied by URC. On the switch, ensure the "NO-LV" contact of the QT switch is wired.



Use 22mm punch.

Figure 7.2: Local QT-Switch Mounting

7.3 Remote QUICK-TRIP® Switch

AC-PRO-NW is provided with terminals for connection to a remote QUICK-TRIP switch (provided by others). 24VDC Aux power to AC-PRO-NW is required for Remote QT.

****** NOTE ******

QUICK-TRIP can be activated (by applying 24VDC, 120VAC, or 125VDC to the remote Quick Trip switch terminals) even when the AC-PRO-NW Local QT switch is in the OFF position. Therefore, if a remote QUICK-TRIP switch is installed, URC recommends installing label(s) or nameplate(s) that indicate the presence and location of the remote QUICK-TRIP switch.

7.4 QUICK-TRIP® Remote Indication

The AC-PRO-NW is provided with terminals for connection to a customer supplied remote QUICK-TRIP indicating light or other device. 24VDC Aux power to AC-PRO-NW is required for this feature. The output is rated 24VDC/120VAC/125VDC 100mA.

7.5 QUICK-TRIP® ON / OFF Control

QUICK-TRIP® arc flash hazard reduction can be activated using local or remote switches (See Sections 7.1 and 7.3) or via three (3) other "soft" methods including the AC-PRO-NW front Keypad, via InfoPro-AC (USB), or the Smart 1-Line HMI. (See Figure 7.4: Breaker Control and Figure 7.3: Front Panel QUICK-TRIP ON/OFF Control.) URC recommends using only one means or the other (use either physical switches OR use a "soft" method).

Control and Logic Notes:

1. If a physical QT switch is connected and in the ON position:
 - a. The only way to turn QUICK-TRIP OFF is by switching the physical switch to the OFF position.
 - b. All "soft" QT control methods are not available.
2. If a physical QT switch is not present or is connected but in the OFF position, then QUICK-TRIP can be turned ON or OFF by using one of the "soft" methods (AC-PRO-NW front panel, InfoPro-AC (USB) software, or Smart 1-Line via RS-485 communications).

To control QUICK-TRIP® mode via the keypad, when at the Main Readings screen, press the "DISPLAY" button, then select "QT", and then turn Quick-Trip ON or OFF using the buttons below. You will need to enter the Security Code (last 4 sigits of serial number) and then confirm you wish to make the setting adjustment. The Quick-Trip Indicating LED on the trip unit will be lit if trip unit is in QT mode.




Figure 7.3: Front Panel QUICK-TRIP ON/OFF Control




Figure 7.4: Breaker Control Window (InfoPro-AC or Smart 1-Line)

Note: To allow remote Quick-Trip control with Smart 1-Line (RS-485), the “Soft QT SW” Modbus option (permission setting) must be enabled locally at the AC-PRO-NW.

8.0 Voltage Divider Module (VDM) (optional)

The optional Voltage Divider Module (VDM) provides the following voltage-based protection and voltage and power calculations:

- Voltage Metering
 - Line-to-Line
- Power Metering: (KW, KVA, KWHr, KVAHr, PF, KWD, KVAD)
- Under-Voltage Trip & Alarm
- Over-Voltage Trip & Alarm
- Phase Loss/Reverse Trip and Alarm
- Reverse Power Trip and Alarm

The VDM is rated for up to 600V three-phase power systems.

****** IMPORTANT ******

On the Masterpact NW breaker, the normal location for the existing voltage taps is the load side of the breaker. If continuous trip unit power is desired (for example, for communications, even when breaker is open) 24VDC Auxiliary power is required.

8.1 Voltage-Based Protection

When equipped with the internal Voltage Divider Module (VDM), the AC-PRO-NW can be used to provide voltage-based protection using the UnderVoltage, OverVoltage, and Phase Loss/Reverse features.

****** IMPORTANT ******

If line voltage is the only source to the trip unit (no current, no 24VDC aux power), it must be present for 5 seconds before a voltage-based trip can occur.

****** IMPORTANT – PHASE LOSS & UV ******

Reminder: Although AC-PRO-NW derives power from the system current (CTs) and from system voltage (VDM), there are some UnderVoltage (UV) or Phase Loss circumstances (i.e. a total power loss, Phase Loss with no current, etc) where the AC-PRO-NW is not powered by the CTs or the VDM. Therefore, if Phase Loss or UV protection is desired in these circumstances, reliable 24VDC Auxiliary power to AC-PRO-NW is recommended.

9.0 SAFE-T-TRIP™ (optional)

The SAFE-T-TRIP remote trip device is available for the AC-PRO-NW. The SAFE-T-TRIP allows an operator to trip open a breaker without standing in front of the breaker. It also provides a way to obtain the breaker mechanism operation speed for the important **first operation**. This is accomplished using the patented Sluggish Breaker feature in the AC-PRO-NW.

The SAFE-T-TRIP device is furnished with a permanently connected 30-foot USB cable, allowing the breaker to be tripped without standing directly in front of the breaker, thus reducing the arc flash hazard risk.

The SAFE-T-TRIP device connects directly to the trip unit Mini-USB port or the door-mounted USB Extender.



The SAFE-T-TRIP device should not be operated while standing in front of a racked in breaker or breaker cubicle. The SAFE-T-TRIP is supplied with a 9V lithium battery, the attached USB cable with magnetic cable wrap (for stress relief), and Instructions, in a durable, waterproof case.



Figure 9.1: SAFE-T-TRIP



Figure 9.2: SAFE-T-TRIP in case

10.0 Sluggish Breaker™ Detection

The AC-PRO-NW patented Sluggish Breaker Detection feature captures the breaker mechanism time when a trip occurs that was initiated by the trip unit. If the breaker mechanism time is in excess of the Sluggish Breaker mechanism time setting (see Section 11.25), an alarm message will appear, and if set, the programmable relay will operate.

If a “sluggish” trip occurs, breaker mechanism maintenance is required.

The “default” settings for this breaker are Sluggish Breaker Threshold: 33ms, and limit switch: 52a.

When the AC-PRO-NW sends a trip pulse to the breaker actuator, the Sluggish Breaker timer starts. The trip unit determines the breaker mechanism time by one of two methods:

- 1) **Limit Switch Method:** Most Masterpact NW breakers are equipped with an existing 52a limit switch that is already wired to the trip unit mounting cradle. The AC-PRO-NW limit switch user setting should be set to “52a”. The trip unit will record the breaker mechanism time based on the change in state of the limit switch. The Sluggish Breaker timer stops when the limit switch changes state. After installation, the user should verify the limit switch operation by reviewing the breaker position on the screen in the “More” menu, and by observing breaker mechanism time in “Trip History”.
- 2) **Zero Current Method:** If a limit switch is NOT present on the breaker, the limit switch user setting should be set to “None”, and the trip unit will record the breaker mechanism time by monitoring the current values. The Sluggish Breaker timer stops when the current is zero. This method records the breaker mechanism time for each breaker pole.

**** NOTE ****

When using the zero current method, the Sluggish Breaker feature requires the pre-trip primary current to be 10% of the CT rating or greater.




Figure 10.1: Sluggish Breaker Screen

11.0 Commissioning the AC-PRO-NW®

Before the AC-PRO-NW trip unit is put into service, it must first be commissioned so it will function. This requires the user to enter all of the pick-up and delay settings into the unit.

The commissioning process normally takes less than a few minutes to complete.

The AC-PRO-NW can be commissioned using the local display screen, or using the InfoPro-AC software application. For commissioning using the local display screen, continue reading this section. For commissioning using the InfoPro-AC software application, see Section 22.0, and the InfoPro-AC help guide included in the application.



**** IMPORTANT ****

The trip unit will NOT FUNCTION as it is shipped from the factory. The user must first COMMISSION the unit as outlined in this Section or Section 11.3 to make it functional.

11.1 Powering-Up the Trip Unit for Commissioning

In normal service, the AC-PRO-NW is powered directly from the breaker mounted CT's. For commissioning, the trip unit can be powered up in any of the following ways:

11.1.1 Internal Battery

Press the "DISPLAY" button to power-up the trip unit using the internal battery.

The trip unit is designed to shut off automatically if none of the push buttons on the face of the unit are pressed for 60 seconds. It is best to have all the desired settings readily available before commissioning the unit when using the battery.

If the unit shuts down before the commissioning process is completed, the process must be started again from the beginning.

11.1.2 USB Power

Connect a laptop, PC, or USB wallpack to the front mini-USB port of the AC-PRO-NW. The unit will be powered continuously, regardless of the power system current and voltage.

11.1.3 24VDC Auxiliary Power

Apply 24 VDC to the "+24VDC Aux Power" terminals on the top Aux connector.

11.2 Un-commissioned Screens

After the AC-PRO-NW is installed on the breaker and powered up, it must be commissioned as follows:

- 1) Press the "DISPLAY" button to turn on the display.
- 2) The "Un-commissioned" message will appear (see figure below).




Figure 11.1: Un-commissioned Screens

Pressing "SET" will start the user settings process. See Section 11.3. Pressing "About" will go to the "URC" menu. The URC menu has links to the Trip Unit ["TU"] Firmware Version. See Figure 11.1: Un-commissioned Screen above.

11.3 Entering & Changing Settings locally




Figure 11.2: Change Settings Menu - Part 1




Figure 11.3: Change Settings Menu - Part 2

SEE SECTION 6.0 FOR MENU NAVIGATION AND TABLE 6-A FOR COMMON SMART BUTTON ACTIONS.

The Neutral screen does not appear if the GF Type or QT-GF Type is set to Ground Return. NP can be turned ON or OFF. NP range: 50 to 200% of LSI Phase Protection..

```

Neutral Protection (NP)
ON
NP-LT          50%
NP-ST          300A
NP-INST        500A
NP-INST        3600A
(Requires Neutral CT)
Back  UP  Down  Enter
    
```

NP-LT Long Time Pickup in Amps
50% to 200% of LT Pickup Setting
NP-ST Short Time Pickup in Amps
50% to 200% of ST Pickup Setting
NP-INST Instantaneous Pickup in Amps
50% to 200% of INST Pickup Setting

The Phase Current Unbalance (U/B) can be set to ON or OFF.

```

Phase Current Unbalance (U/B)
Pickup          20%
Delay           5 Sec
Back  Alarm  Off  Enter
    
```

Phase Current Unbalance Pickup in Amps
20 to 50% in 5% increments
Time Delay Adjustable from
1 to 60 Seconds in 1 Second Steps

UV and OV Notes:

1. These screens only appear if the optional Voltage Divider Module (VDM) is connected.
2. The UV and OV functions are set using Line-to-Line voltages.
3. The UV and OV both have Trip and Alarm functions that can be turned ON or OFF. If the Alarm is ON, the Alarm Output Relay will be operated if a UV or OV event occurs.

```

UNDERVoltage Trip (UUT)
UV TRIP          ON
UV Pickup        xxxV L-L
UV Delay         xxx Sec
Back  UP  Down  Enter
    
```

UV Pickup range & steps:
100 to 600V L-L, 1V Steps
If OV Trip or Alarm are ON, the highest UV Pickup setting available is 12V below OV Pickup.
UV Delay range & steps:
Inst, 1 to 255 Seconds, 1S Steps

```

UNDERVoltage Alarm (UUA)
UV ALARM         ON
UV Pickup        xxxV L-L
UV Delay         xxx Sec
Back  UP  Down  Enter
    
```

OV Pickup range & steps:
100 to 660V L-L, 1V Steps
If UV Trip or Alarm are ON, the lowest OV Pickup setting available is 12V above UV Pickup.
OV Delay range & steps:
1 to 255 Seconds, 1S Steps

```

OVERVoltage Trip (OUT)
OV TRIP          ON
OV Pickup        xxxV L-L
OV Delay         xxx Sec
Back  UP  Down  Enter
    
```

Ph Loss/Rev Notes:

1. These screens only appear if the optional Voltage Divider Module (VDM) is connected.
2. The Phase Loss/Rev function has Trip and Alarm functions that can be turned ON or OFF. If the Alarm is ON, the Alarm Output Relay will be operated if an Alarm condition occurs.
3. The system rotation is only set and displayed if Ph Loss/Rev trip or alarm is enabled.
4. The NegSeqOV pickup is only set and displayed if Ph Loss/Rev trip or alarm is enabled.

```

OVERVoltage Alarm (OVA)
OV ALARM         ON
OV Pickup        xxxV L-L
OV Delay         xxx Sec
Back  UP  Down  Enter
    
```

```

Ph Loss/Rev (Ph-Loss)
Trip            ON
Delay           XX Sec
Alarm           ON
System Rotation ABC
NegSeq-OV Pickup XX%
Back  ON  OFF  Enter
    
```

Phase Loss /Reverse Delay
2 to 60 Sec in 1 sec steps
Phase Loss/Reverse Alarm
2 Sec ON delay & 1 Sec OFF delay (fixed)

```

UP  DOWN
ABC  CBA
    
```

System Rotation
ABC or CBA
Negative Sequence OV % Pickup
10-30%. Default is 20% (10% is more sensitive and 30% is less sensitive)

```

Reverse Power: TRIP
Pickup          40 kW
Delay           2 Sec
Back  Alarm  Off  Enter
    
```

Reverse Power
Can be set to Off, Alarm or Trip
Pickup based on CT rating
25 to 830 KW in 5 KW steps (1000A CT)
Min=3% of CT rating x 480V x 1.732 (sqrt 3)
Max=100% of CT rating x 480V x 1.732 (sqrt 3)
Delay
2 to 60 Sec in 1 sec steps

SEE NEXT PAGE.

Figure 11.4: Change Settings Menu - Part 3




Figure 11.5: Change Settings Menu-Part 4

11.4 Security Code

The security code is the last four (4) digits of the serial number. See Section 4.0 for location of serial number. See Figure 11.2.

NOTE: For convenience, the AC-PRO-NW offers a "Test Mode". When the AC-PRO-NW is in Test Mode, the need for the Security Code is disabled for one (1) hour, after it is entered once. See Section 14.1.1

11.5 CT Rating

After the Security Code is entered, the first setting is the CT Rating in amps. The CT tap can range from 50 amps to 5,000 amps in 25 amp steps or 5250 amps to 6250 amps in 250 amp steps. The highest CT setting is 6300 amps.

The CT rating entered into the trip unit **must** correspond to the actual rating of the phase and neutral CT. See Figure 11.2.

11.6 Power Flow Direction

The power flow direction setting only applies when a VDM is connected. When the CT wiring polarity matches Figure 5., the power flow direction should be set to "NORMAL". When the CT wiring polarity is the opposite of Figure 5., the power flow Direction should be set to "REVERSE".

Note: This setting affects the KVA, KVAHr and KVD values displayed by the trip unit. See Section 13.0. See Section 13.0. The Power Flow direction also affects the Reverse Power calculation. See Section 11.24.

11.7 Frequency

Set the AC-PRO-NW frequency to match the power system frequency. The setting options are 50 Hertz and 60 Hertz. See Figure 11.2

11.8 CT Auto-Polarity Correction

The AC-PRO-NW includes a user selectable feature that can turn CT polarity correction "ON" or "OFF". If set to "ON", the Phase and Neutral CTs are checked to determine whether the polarity may be reversed from expected rotation and corrected if reversed. A reversed polarity for a Phase CT would typically show up as Ground current on an unfaulted system. (Note – Ground Fault (GF) type would need to be set to "Residual" for polarity sensing which utilizes the vector summation of the three phase CTs minus the Neutral CT current for 4-wire systems.) This incorrect Phase polarity appears to be GF current when in reality there is a polarity issue between the three Phase CTs. If the Neutral CT polarity is reversed from the Phase CTs (adding instead of subtracting), the trip unit may measure GF current that is twice the Neutral current when in reality there is no GF current. The CT auto-polarity setting of ON will correct this false GF current due to a Neutral CT polarity issue. (Please be aware for the polarity detection, a minimum of 10% of the CT sensor rating is required.) See Figure 11.2.

11.9 CT Open circuit detection

The AC-PRO-NW can detect a CT open circuit condition and alarm if the condition is present. The condition is checked when non-battery power is applied.

11.10 Long Time (LT)

The Long Time (LT) settings screen includes the following settings: Enabled (ON or OFF), pick-up, delay, and thermal memory.

See Figure 11.2 for Long Time protection settings notes, ranges, steps, and options.

Long Time (LT) protection is ON, unless the trip unit is ordered with the "LT can be turned OFF" option.

Please note that the LT trip time is not a constant value, but is a function of breaker current. For lower currents the trip time is longer, and for higher currents the trip time is shorter. See Figure 18.1 for Time Current Curve.

See Section 18.1 for LT Trip Times.

11.11 Thermal Memory

The AC-PRO-NW trip unit has a thermal memory feature for the following protective functions:

- Long Time (LT) (set at Long Time screen)
- Short Time (ST)
- Ground Fault (GF) (always on)
- Neutral Overload (set at Neutral Overload screen)

The thermal memory feature for LT and ST can be turned on or off at the LT screen. See Figure 11.2.

Thermal memory for the GF function is always on and cannot be turned off. The GF thermal memory feature provides protection against "sputtering" ground faults.

Except for unusual conditions, it is recommended that the thermal memory feature for LT and ST should be turned on.

Cycling overloads that are not above the LT Pick-Up long enough to cause a trip can still lead to thermal damage to wiring and equipment. With thermal memory turned on, a cycling overload can still produce a LT trip to protect cables and equipment even if any individual overload event did not persist long enough to directly cause a LT trip.

With thermal memory turned off, an overload that drops below the LT Pick-Up will reset the LT trip register. If the current goes above the LT Pick-Up again, the LT trip register starts from zero.

11.12 Short-Time (ST)

The Short Time (ST) settings screen includes the following settings: enabled (ON/OFF), pick-up, delay, and I²T ramp (ON/OFF).

See Figure 11.3 for ST protection settings, notes, ranges, steps, and options.

**** NOTE ****

The trip unit does not allow setting both the ST and Instantaneous to be set to OFF at the same time.

See Figure 18.1 for the Time Current Curve.
See Section 18.2 for ST Trip Times.

11.13 Instantaneous (I)

The Instantaneous (I) settings screen includes the following settings: enabled (ON/OFF) and pick-up.

See Figure 11.3 for Instantaneous settings, ranges, and steps.

****** NOTE ******

The trip unit does not allow setting both the ST and Instantaneous to be set to OFF at the same time.

See Figure 18.1 for the Time Current Curve.

In addition, the Instantaneous settings screen displays the Instantaneous override and Instantaneous-on-close features if they are enabled. These features are fixed and set at the factory. See below: Instantaneous Override (I-OVRD): The AC-PRO-NW is configured at the factory with this feature ON. If the feature is ON, a fixed Instantaneous pickup of 15 times the CT rating is applied. In some applications, this feature is enabled at the factory to protect the specific breaker this trip unit is paired with. Unless specified at the time of order, AC-PRO-NW trip units are normally configured with this feature ON.

Instantaneous-on-Close (I-CLOS): The AC-PRO-NW is configured at the factory with this feature ON. If this feature is ON, a fixed Instantaneous pickup of 15 times the CT rating is applied for only the first 6 cycles (96ms for 60Hz) after initial current flow: after the trip unit powers up, or after the current transitions from very low current (less than 2.5% of CT rating), to current greater than 15 times the CT rating. Unless specified at the time of order, AC-PRO-NW trip units are normally configured with this feature ON.

11.14 Ground Fault (GF) Protection

The Ground Fault screens include the following settings: GF trip type, pick-up, delay, slope. In addition, if the GF trip function is turned OFF, a GF Alarm function can be turned ON.

GF type can be set to residual, ground return, or OFF)

The residual GF method calculates a vector sum of the three phase currents (and neutral current if applicable) and determines the fundamental frequency component.

The ground return method is used for applications where a ground return CT directly measures the GF current, and the AC-PRO-NW calculates the fundamental value.

See Section 5.1.1 for typical wiring diagrams of the two ground fault methods.

See Figure 11.3 for Ground Fault settings notes, ranges, steps, and options.

See Figure 18.2 for Ground Fault Time Current Curve.

****** NOTE ******

On a 4-wire system, a neutral CT must be installed to avoid nuisance GF trips.

****** NOTE ******

Due to possible CT saturation, RMS currents greater than 14 times the CT rating are not considered in the GF protection calculations. The ST and/or Instantaneous functions will provide protection for these currents.

****** IMPORTANT ******

To implement GF protection on the main breakers and the tie breaker of a double ended 4-wire substation, see the following Technical Bulletin:

http://www.utilityrelay.com/Side_Bar/Technical_Bulletins.html

11.15 Programmable Relay Outputs

The Programmable Relay Outputs can be set to operate for "Alarm" conditions, or to operate for "Zone Block (*ZB)", (*ZB requires current > Inst, ST, or GF Pickup) conditions to block upstream non-URC devices.) The Programmable Relay Outputs can also be disabled by setting it to "OFF". for additional information.

11.15.1 Alarm

If the Programmable relay function is set to "Alarm", then the relay will operate based on Alarm settings. See Figure 11.3: Change Settings Menu - Part 2 and Section 5.5.1 for additional information. .

11.15.2 Zone Block Relay Operation

If the Programmable relay function is set to "Zone Block", then the Zone Block Relay

If the Programmable relay function is set to "Zone Block", then the Zone Block Relay Operation screen will appear. The relay (dry contact) can be programmed for (current > Inst, ST, or GF Pickup) conditions to block upstream non-URC devices.

See Figure 11.3: Change Settings Menu - Part 2 and Section 5.5.8.2 for additional information.

11.16 High Current Alarm

The High Current Alarm feature includes a dedicated pickup setting, resulting in alarm when any phase current exceeds the setting for 2-4 seconds. See Figure 11.3 for the High Current Alarm pickup setting range.

11.17 QUICK-TRIP® Instantaneous (QT-I)

The QT-I pickup range and steps are the same as the Instantaneous pickup range and steps.

See Figure 18.3 for the QUICK-TRIP Time Current Curves (TCC).

The QT- I function does not have an OFF setting. Quick-Trip is turned ON or OFF using the QUICK-TRIP ON-OFF selector switch. If the AC-PRO-NW QUICK-TRIP switch module is not installed, then this function can be turned on from the front panel or via Modbus or the Smart 1-Line. See Section 7 for additional information.

11.18 QUICK-TRIP Ground Fault (QT-GF)

The QUICK-TRIP GF feature has two settings: QT-GF type and QT-GF pick-up.

If GF type is set to OFF, QT-NG type can be set to residual, return, or OFF. If GF type is set to residual or return, the QT-GF type can only match it or be turned OFF.

The QT-GF pick-up range and steps are the same as the GF pickup range and steps.

If the AC-PRO-NW QUICK-TRIP switch module is not installed, then this function can be turned on from the front panel or via Modbus or the Smart 1-Line. See Section 7 for additional information.

See Figure 18.3 for the QUICK-TRIP Time Current Curves (TCC).

11.19 Neutral Protection (NP) Settings

Neutral Protection can be set to Trip based on a percentage of the Long, Short and Instantaneous Pickup Settings. The Neutral Protection range is adjustable from 50% to 200% of LSI. (Note: this protection requires a neutral CT.) Long, Short and Instantaneous functions, if turned OFF, will be turned OFF for Neutral Protection (NP).

See Section 18.5 for Neutral Protection (NP) Example. See Figure 18.1 for the Neutral Protection Time Current Curves (TCC) as the Neutral Protection is the same as the Overload LSI curve multiplied by the Neutral Pickup (NP) Setting.

**** NOTE ****

Neutral Protection (NP) cannot be enabled if the Ground Fault (GF) type is set to ground return. This is because with the ground return method, the neutral CT input is used for GF protection and thus cannot be used for neutral protection.

11.20 Phase Current Unbalance (U/B)

The Phase Current Unbalance setting should not be confused with the Ground Fault (GF) function. The Phase Current Unbalance function is a motor protection function and should only be used on breakers feeding large balanced motor loads where currents are normally balanced.

See Figure 11.4: Change Settings Menu - Part 3 for Settings notes, ranges, steps and options. See Figure 18.5 for Phase Current Unbalance Time-Current Curve.

11.21 Undervoltage (UV)

This setting only applies if the AC-PRO-NW is installed with the optional Voltage Divider Module (VDM).

The Undervoltage (UV) function of the AC-PRO-NW utilizes RMS voltages and a definite time delay, to provide three-phase UV protection.

The UV function is disabled under the following conditions:

- If a Secondary Injection Test set is connected.
- After a UV trip, repeated UV trips are blocked until current is re-established, until the limit switch changes state (if used), or until the UV condition goes away.
- When the AC-PRO-NW is in "Test Mode". See Section 14.1.1

11.21.1 Undervoltage

UnderVoltage (UV) function is available in units equipped with the internal Voltage Divider Module. UnderVoltage protection uses line-to-line voltage magnitude only, with adjustable UnderVoltage pickup and delay settings. See Figure 11.4 for settings information.

The UV function is disabled under the following conditions:

- If a Secondary Injection Test set is connected.
- After a UV trip, repeated UV trips are blocked until current is re-established, until the limit switch changes state (if used), or until the UV condition goes away.
- When the AC-PRO-NW is in "Test Mode". See Section 14.1.1

UnderVoltage**IMPORTANT

For Undervoltage trips and/or alarms to occur, **at least one (1)** of the following conditions must be present:

1. The Phase A-to-B voltage must be greater than 90V, OR
2. At least (1) phase current must be greater than 10% of the CT rating, OR
3. 24VDC Auxiliary power must be present.

**** IMPORTANT ****

A "3PH INST" option is available in the UnderVoltage feature delay settings. If this setting is selected by the user, this allows a UV trip to occur in the event of a total power loss. If all 3 phases are lost (blackout), a trip will instantaneously occur while the unit is powering down. All 3 phases must be below the pickup setting for at least 0.13 seconds to guarantee a trip will occur. If all 3 phases are interrupted for only 0.06 seconds or less, a trip will not occur. (the unit will ride through)

11.22 Overvoltage (OV)

This setting only applies if the AC-PRO-NW is installed with the optional Voltage Divider Module (VDM).

The Overvoltage (OV) function of the AC-PRO-NW utilizes voltage and a definite time delay, to provide three-phase OV protection.

See Figure 11.4 for OV settings notes, ranges, steps, and options.

The OV function is disabled under the following condition:

- After an OV trip, repeated OV trips are blocked until current is re-established, until the limit switch changes state, or until the UV condition goes away.
- When the AC-PRO-NW is in "Test Mode". See Section 14.1.1.

**** IMPORTANT ****

Use caution when using the Overvoltage (OV) Trip function on Non-solidly grounded systems.

11.23 Phase Loss / Reverse (Φ -LOSS)

The Phase Loss / Reverse (Φ -LOSS) feature utilizes Negative Sequence Overvoltage calculations to determine if a Phase Loss or Reverse Phase condition is present.

See Figure 11.4 for Phase Loss / Reverse settings notes, ranges, steps, and options.

The Phase Loss/Reverse function is disabled under the following conditions:

- If a Secondary Injection Test set is connected.
- After a Phase Loss/Reverse trip, repeated trips are blocked until current is re-established, until the limit switch changes state (if used), or until the Phase Loss condition goes away.
- When the AC-PRO-NW is in "Test Mode". See Section 14.1.1

**** IMPORTANT ****

For Phase Loss/Reverse trips and alarms to occur, at least one the following conditions must be present:

1. At least (1) phase current must be greater than 10% of the CT rating, OR
2. The Phase A-to-B voltage must be greater than 90V, OR
3. 24VDC Auxiliary power must be present.

In order to provide Phase Loss / Reverse protection, the power "System Rotation" setting of "ABC" or "CBA" must be entered correctly. If the system rotation is not known, the Phase Loss/Reverse Alarm feature can be used as a check, without initiating a trip.

Determining System Rotation:

1. Remove the breaker from service.
2. Ensure the VDM phasing is wired correctly (i.e. Phase A breaker stab through fuse block to AC-PRO-NW VDM phase A, etc).
3. Set Phase Loss/Reverse Trip to OFF.
4. Set Phase Loss/Reverse Alarm to ON.
5. Set System Rotation to ABC.
6. Set NegSeq-OV Pickup to 20%.
7. Save Settings.
8. Rack the breaker into the connected position.
9. Verify the VDM reads 3-phase voltage.
10. If a Phase Loss/Reverse Alarm occurs, then the System Rotation setting is not correct. If a Phase Loss/Reverse Alarm does not occur, then the System Rotation ABC setting is correct.

**** NOTE ****

In multi-source applications (i.e. Main-Tie-Main): Phase Loss protection will NOT provide blown fuse protection on tie breakers, or on main breakers where sources can be paralleled, since the VDM taps may be on "wrong" side of the fuse, since multiple sources exist.

11.24 Reverse Power

The Reverse Power Setting can be set to TRIP, ALARM or OFF. The range is 3 to 100% of the rated Full Load KW. The Reverse Power Trip / Alarm Time Delay range is 2 to 60 seconds.

See Figure 11.4 for setting screen.

11.25 Sluggish Breaker Setting

The Sluggish Breaker setting range is 20ms – 100ms. The default setting for this breaker is 33ms.

The following steps are recommended for confirming the Sluggish Breaker setting on a recently serviced breaker with a mechanism in good operating condition:

1. Perform Primary or Secondary Injection to initiate a ST or LT trip; or use the SAFE-T-TRIP device to initiate a trip. If using SAFE-T-TRIP on a breaker that does not have primary current flowing through it, or if using Secondary Injection, a 52a or 52b limit switch must be wired to AC-PRO-NW.
2. Use the trip history menu to review the recorded breaker mechanism times of the trip initiated in step 1 above. The breaker mechanism times should be in the 20ms to 100ms range. The total trip time (different than breaker mechanism time) should conform to the Time Current Curve in Figure 18.1.
3. URC recommends setting the Sluggish Breaker time to be 17ms greater than the recorded mechanism time from step 2.

See Figure 11.5 for Sluggish Breaker setting screen.

See Section 10.0 for additional information about the Sluggish Breaker feature.

11.26 Alarm Settings

The Alarm settings configuration occurs via two alarm settings screens, where the alarm relay can be set to occur for any combination of events. If the setting is "ON", the relay will operate for that particular event/condition. See Figure 11.3, Figure 11.4, and Figure 11.5 for alarm relay settings options and notes.

Refer to Section 5.5.1 and Table 5-A for additional information about the programmable relay.

11.27 Close Breaker Output Setting

If the Masterpact NW breaker is equipped with a breaker close coil, the AC-PRO-NW is capable of closing the breaker via the front panel, USB communications, wireless communications, or RS-485 Modbus Communications. The breaker must be wired to do so, and this setting must be set to ON.

11.28 Limit Switch Type Setting

If a limit switch is wired to the AC-PRO-NW, the contact type is set at this screen. Most Masterpact NW breakers are equipped with an existing 52a limit switch that is already wired to the trip unit mounting cradle. The AC-PRO-NW limit switch user setting should be set to "52a".

Note that this setting affects the Sluggish Breaker detection method. See Section 10.0.

11.29 Date/Time Format

The date format can be set to MM/DD/YY, DD/MM/YY, or YY/MM/DD. (M=Month, D=Day, Y=Year).

11.30 Communication Settings

The AC-PRO-NW is capable of communicating over an RS485 network via Modbus RTU protocol. The RS485 communications screen includes the following settings:

Communications Enabled: Set to ON if RS485 communications is desired.

Address: Each trip unit that shares the same twisted pair must have a unique address. The address identifies each individual trip unit connected to the same twisted pair.

Note: two trip units can have the same Address as long as they are not connected to the network via the same twisted pair cable.

The address is selectable from 1 to 247, in increments of 1. In most applications, only addresses 1 through 32 will be used due to the limitations of RS485 communications.

Baud Rate should be selected to match the baud rate of the master communicating device (i.e. PC, gateway, etc.).

Parity should be set to match the parity of the master communicating device (i.e. PC, gateway, etc.).

Forced Trip: If enabled, this feature permits tripping of the breaker via a forced trip command over RS485 communications.

Settings Change Over Communications: If enabled, this feature permits the user to make settings changes via the communications network. Otherwise, settings can only be changed at the AC-PRO-NW using the smart buttons or using the local USB connection.

NOTE: The CT settings can only be changed at the AC-PRO-NW.

Soft QT Sw (Quick-Trip Control via RS-485): If enabled, this feature permits the user to change the Quick-Trip mode via RS-485 Communications.

See Figure 11.5 for setting options and Section 23.0 for additional Communications information.

11.31 Saving Settings

Once the last setting is entered, the "Save Settings?" screen will appear. The save settings screen also provides a reminder that if the "Save" button is pressed, the settings will be saved, logged, and time stamped as a "Settings Change". The settings change time stamp is stored and available via Modbus communications.

Pressing "Exit" will return to the Main screen.
Pressing "Back" will return to the previous setting screen.

11.32 Settings Verification

Once the settings are saved, the "REV" and "OK" buttons are available at the "Settings Saved" screen.


Pressing "REV" will lead to the review settings sequence.
Pressing "OK" will lead to the main screen.

To complete the entering or changing settings process, press "REV" to review and confirm all settings entered.

The settings review sequence is very similar to the settings change sequence, except the settings are only viewed and cannot be changed. The existing settings are viewed and navigated with the "Next" and "Back" buttons.
See below and Figure .

11.33 Settings Review

Settings can also be changed, reviewed, saved, and printed using the InfoPro-AC software application.



To Settings
Review Sequence.

Figure 11.6: Settings Screen - Review Button

See Section 6 for the settings review sequence.

11.34 Time & Date Settings

See Section 6.4.1 for the time & date Settings.

NOTE: It is important to set the time & date for time stamping of events. The clock relies on the CR2 lithium battery (front accessible).

12.0 Trip History

The AC-PRO-NW stores the trip data for the last 8 trip events. The stored trip data includes the following:

1. Trip counts
2. Trip type (see Table 12-A for types)
3. Time stamp (date and time).
4. Trip number (1-8, assigned by trip unit) (if trip is the "Last trip", this will be identified on the screen).
5. Phase currents and voltages
6. Neutral and ground currents
7. Breaker mechanism time for each phase
8. Waveforms can be viewed using InfoPro-AC software application only. See Section 23.0.

This data can be accessed using the Trip History Menu.
See Figure 12.1.

NOTE: The date and time must be set properly, and a fresh battery must be installed to ensure accurate trip history date and time stamps.

Trip Type Abbreviation	Trip Type Description
LT	Long Time
ST	Short Time
I	Instantaneous
I-OVRD	Instantaneous Override
I-CLOS	Instantaneous on Close
GF	Ground Fault
NP	Neutral Protection (NP)
QT-I	QUICK-TRIP Instantaneous
QT-GF	QUICK-TRIP Ground Fault
U/B	Phase Current Unbalance
UV	Under Voltage
OV	Over Voltage
Forced	Modbus Communications trip
SAFE-T	SAFE-T-TRIP Hand held device trip
Ph Loss/Rev	Phase Loss / Reverse (NSOV)
Rev Power	Reverse Power (v4)
GFT	Ground Fault Test Trip

Table 12-A: Trip Types

The trip history data, including the associated waveform capture data, can be viewed, saved and printed using the InfoPro-AC software application. All trip unit data is also available via RS485 Modbus RTU communications.

To ensure accurate recording of breaker mechanism times, and proper Sluggish Breaker™ Detection, the breaker position contact user setting must be set properly. See Sections 10.0 & Figure 11.5: Change Settings Menu-Part 4 .

The AC-PRO-NW uses multiple methods to determine trip currents and voltages. However, some Instantaneous trips may occur too rapidly for AC-PRO-NW to report RMS trip values. For these trips, AC-PRO-NW will report "> Pickup value" for the current values for all three phases.

See Figure 12.1 for the trip history screens navigation map.




Figure 12.1: Trip History Menu

13.0 Normal Operations & Readings

During normal operation, the trip unit display screen will be off and in its power saving mode. See Section 11.1 for trip unit power information. When the "DISPLAY" button is pressed during normal operation (no trips, errors, alarms, etc), the trip unit will display current and voltage (if equipped with VDM) readings. The neutral and GF currents will only be displayed if neutral or GF protective functions are turned on. See below. The "XXXX" digits will display actual readings.




Figure 13.1: Main ("Readings") Screen

- The left column displays Currents in Amps for Phases A, B, C, Neutral and Ground Fault.
- The right column displays Voltages and Frequency

Breaker Current Less than 10% of CT Rating:

When the currents are less than about 10% of the CT rating, the display will display "LOW" for currents.

Breaker Current Greater than 10% of CT Rating:

If the breaker current is greater than about 10% of the CT rating, the current readings will be displayed.

Line-to-Line Voltages (if equipped with VDM):

"LOW" will be displayed if the Line-to-Line voltage is 90V or below.

"N/A" will be displayed if the Voltage cannot be determined.

Note: If voltages and voltage labels ("Vab, Vbc, Vca") do not display, the AC-PRO-NW is either not equipped with a VDM, or the VDM is not properly connected to the AC-PRO-NW. Contact URC.

See Section 8.0 for additional information about the Voltage Divider Module (VDM).




Figure 13.2: Power and Energy screen (if equipped with VDM)

- KWhr: Total Real Energy usage, measured in KiloWatt-Hours. This value increments and decrements depending on the power flow direction and Power Flow Direction user setting. See Section 11.6.
- KVAHr: Total Apparent Energy usage, measured in KiloVoltAmpere-Hours. This value only increments.
- KW: Total Real Power, measured in KiloWatts.
- KVA: Total Apparent Power, measured in KiloVolAmperes.
- PF: Total Power Factor
- Demand Period: Time Period Peak Demand is calculated.
- KWD: Kilowatt Demand (Last, Peak)
- KVAD: Kilovar Demand (Last, Peak)
- Demand values =
 - (KWHrs for period) / Period
 - (KVAHrs for period) / Period

Instantaneous Power Values (if equipped with VDM):

- "LOW" or "N/A" is displayed if the power cannot be determined, most likely because system voltage (i.e. 480V) is not present at the VDM, or if voltage or current is too low.
- The KW values are affected by the direction of the power flow, and the Power Flow Direction user setting. See Section 11.6.

Energy Values (if equipped with VDM):

- Energy values increment if the current for a particular phase is above 3% of the CT rating and the phase voltage is above 90V.

Frequency is displayed based on Phase A current.

14.0 Testing

A "primary injection" test is recommended as the final test of the AC-PRO-NW.

If residual GF is used, it must be temporarily turned off when testing the other trip functions.

14.1 Commission the Trip Unit

Before proceeding with the normal primary injection tests, the trip unit must be commissioned to make it functional. See Section 11.0 for the commissioning procedure.

It is best to use the final pick-up and time delay settings if they are known. If not, use typical settings for the primary injection test.

14.1.1 Test Mode

For Testing convenience, AC-PRO-NW offers a "Test Mode". When the AC-PRO-NW is in Test Mode, all Voltage Protection is temporarily disabled, and the need to enter the Security Code to change settings is temporarily disabled. Though Test Mode is automatically turned OFF after 60 minutes, it should always be manually turned OFF after testing is complete. See the screens in Figure 14.1.




Figure 14.1: Test Mode Screens

14.2 Long Time Trip Test

If residual GF is used, make sure it is temporarily turned off.

To test the LT Pick-Up, increase the current until the "Pick-Up" LED illuminates.

The injected current should correspond to the programmed LT pick-up setting. Verify that the correct phase is indicated on the display.

To test the LT trip time, first calculate the trip time based on the value of the test current that will be applied. Use the formula in Section 18.1 or the chart in Section 15.3.

**** NOTE ****

A simple shortcut is to note that the trip time (center of the curve) at 3 times the LT pick-up current is 4 times the LT Delay setting.

For example:

If LT Pick-Up is 1600A and Delay is 10.0S, then the trip time at 4800A (3 times 1600A) is 40 sec. (4 times 10 sec).

14.3 Short Time Trip Test

If residual GF is used, make sure it is temporarily turned off.

To test the ST pick-up, temporarily set ST I²T off and apply a short pulse of current that is 10% or 20% less than the ST pick-up setting. Continue applying short pulses of current while increasing the current for each pulse until a ST trip occurs. The first current where a ST trip occurred is the ST pick-up.

To test the ST delay, turn ST I²T on again (if applicable) and apply a current that is at least 10% greater than the ST pick-up current.

The trip time should fall within the time band shown on the Time-Current-Curves.

**** NOTE ****

To bypass Instantaneous-on-Close (I-CLOS) when primary injection testing at high currents, power the AC-PRO-NW prior to applying current using USB power via a laptop or a mini-USB wallpack. See section 11.13 for I-CLOS description.

14.4 Instantaneous Trip Test

If residual GF is used, make sure it is temporarily turned off.

Test the Instantaneous pick-up and trip time in the same manner as ST in Section 14.3.

14.5 Neutral Protection (NP) Trip Test

If residual GF is used, make sure it is temporarily turned off.

If Ground Return GF is used, NP cannot be used.

To perform a primary injection test of the NP function, temporarily shift the Phase C CT secondary wires to the neutral CT input terminals on the AC-PRO-NW. Connect a laptop, PC, or USB wallpack to the front mini-USB port of the display to power the trip unit. Primary injection into Phase C will simulate neutral current. If this testing method is not preferred, the NP function can be tested using the Secondary Injection Test Set. See Section 15.0.

Test the Neutral LSI Pick-up and trip time in the same manner as LT in Section 14.2 based on the Neutral Protection pickup setting percentage.

**** NOTE ****

Only Phase current will power the AC-PRO-NW. When doing primary injection testing of the NP, the AC-PRO-NW must be powered via 24VDC or the USB port.

14.6 Ground Fault Trip Tests

14.6.1 Residual Ground Fault Trip Test

When the AC-PRO-NW is set for residual GF protection, the trip unit calculates ground fault current.

With GF Pick-Up and Delay set to the required values, primary injection testing any one of the three poles will provide a GF trip.

Test the GF Pick-Up and trip time in the same manner as ST in Section 14.3.

14.6.2 Ground Return Fault Trip Test

When the AC-PRO-NW is set for ground return GF protection, the neutral current input is used for direct measurement of the GF current.

To perform a primary injection test of ground return GF protection, temporarily shift the Phase C CT secondary wires to the Neutral CT input terminals on the AC-PRO-NW. Connect a laptop, PC, or 24VDC wallpack to the front mini-USB port of the display to power the trip unit. Primary injection into Phase C will simulate ground return current. If this testing method is not preferred, the ground return GF function can be tested using the Secondary Injection Test Set. See Section 15.0.

Test the GF pick-up and trip time in the same manner as ST in Section 14.3.

14.7 QT-GF Trip Test

To test QT-GF the AC-PRO-NW QUICK-TRIP switch module must be connected to the trip unit as shown in Figure 7.1.

With QT-GF pick-up set to the required value and the QUICK-TRIP selector switch turned to the on position, testing any one of the three poles will provide a QT-GF trip.

Test the QT-GF pick-up and trip time in the same manner as the normal GF function.

14.8 CT Phasing Test for GF

Proper breaker CT polarity is always recommended, and is required for residual GF and residual QUICK-TRIP GF protection. Without proper CT polarity wiring, a nuisance GF trip will probably occur. **With the breaker in service on a 3-phase system, the last trip data with a reversed polarity phase CT will show the GF current magnitude as approximately two times the phase current of the CT connected in reverse polarity.**

Since primary injection testing normally tests only one phase at a time, a breaker CT with reversed polarity will not be detected with the normal tests. By using the following method, a primary injection test set can be used to test for proper CT polarity.

Figure 14.2 and Figure 14.3 show a method to verify that the breaker CT polarities match. The setup in Figure 14.1 verifies that the CT polarities of Phase A and Phase B match. The setup in Figure 14.3 verifies that the CT polarities of Phase B and Phase C match.

It is only necessary to inject a current slightly greater than the GF Pick-Up setting and to verify that a GF trip does not occur.




Figure 14.2: Phase A & B, CT Polarity Test




Figure 14.3: Phase B & C, CT Polarity Test

If a GF trip does occur, determine which CT has the reversed polarity. Reverse the secondary connections at the CT to correct the reversed polarity.

The breakers shown in the Figures above have the CTs on the load side. Use exactly the same method if the CTs are on the breaker line side or if they are staggered.

If a neutral CT is used, its polarity must match the polarity of the breaker mounted CTs.

14.9 QT-I Trip Test

To test QT-I the AC-PRO-NW QUICK-TRIP switch module must be connected to the trip unit as shown in Figure 7.1 or the Quick-Trip mode must be active from the front screen or via Smart 1-Line or Modbus. See Section

With QT- I pick-up set to the required value and the QUICK-TRIP selector switch turned to the on position, test all three breaker poles in the same manner as the normal Instantaneous function.

14.10 Phase Current Unbalance Trip Test

The Phase Current Unbalance trip function is not easy to test with a single phase, high current test set.

Figure 14.4 illustrates a method to test the U/B trip function. It requires using cable or bus to jumper the breaker poles as shown. This generates an unbalanced current of 50% or slightly more depending on how equally the current is split between the two poles.

It is only necessary to inject a current equal to 20% or 30% of the CT rating for this test. It is only possible to test the Current Unbalance trip time and not the Current Unbalance Pick-Up with this method.




Figure 14.4: Phase Current Unbalance Test

14.11 Undervoltage (UV) Test

To test the UV trip or alarm function, a voltage source, and a timer is needed.

Since both a current test set and a voltage source will be used, ensure the AC-PRO-NW voltage connections are isolated from the breaker poles by removing the fuses from the fuse block that feeds the VDM (Voltage Divider Module). Make the temporary testing connections shown in Figure 14.5. The voltage source can be 120VAC (voltage must be at least 90VAC). Verify that the Phase A voltage is indicated on the display.

The UV delay feature can be tested with a timer. The UV function is "definite time", so the delay remains the same regardless of the severity of the undervoltage.

****** IMPORTANT ******

If line voltage is the only source to the trip unit (no current, no 24VDC aux power), it must be present for 5 seconds before a voltage-based trip can occur.




Figure 14.5: Voltage Test (temporary connections)

Undervoltage Test Notes:

- 1) After a UV trip occurs, repeated UV trips are blocked until current is re-established, or until the breaker is closed (if a 52a or 52b limit switch is connected).
- 2) If a UV alarm occurs, it is latched and must be reset using the display and push buttons.
- 3) Refer to Section 11.21 for additional Undervoltage information.

****** IMPORTANT ******

The Undervoltage function will not operate in the event of a total phase loss or total system outage. The UnderVoltage function is not "Phase Loss" protection.

Undervoltage Test Procedure:

- 1) Set the AC-PRO-NW UnderVoltage Trip or Alarm setting to ON.
- 2) Apply 120VAC across terminals A & B. (must be at least 90VAC)
- 3) The UV trip or alarm should occur within +/- 0.25 seconds of the UV time delay setting.

****** IMPORTANT ******

If line voltage is the only source to the trip unit (no current, no 24VDC aux power), it must be present for 5 seconds before a voltage-based trip can occur.

14.12 Overvoltage (OV) Test

To test the OV trip or alarm function, a variable voltage source, and a timer is needed.

Make the temporary connections shown in Figure 14.5: Voltage Test. The maximum voltage of the variable voltage test source should be at least 10% above the programmed OV pick-up setting. Verify that the Phase A voltage is indicated on the display.

The OV delay feature can be tested with a timer. The OV function is definite time, so the delay remains the same regardless of the severity of the overvoltage.

Overvoltage Test Notes:

- 1) After an OV trip or occurs, repeated OV trips are blocked until current is re-established, or until the breaker is closed (if 52a or 52b limit switch is connected).
- 2) If an OV alarm occurs, it is latched and must be reset using the display and push buttons.
- 3) OV is disabled if the Secondary Injection Test Set auxiliary power is connected to AC-PRO-NW.

Overvoltage Test Procedure:

- 1) Apply voltage at least 10% below the OV Pickup setting.
- 2) No OV trip should occur.
- 3) Increase the voltage to at least 10% above the OV Pickup setting and start the timer.
- 4) An OV trip should occur within +/- 0.25 seconds of the OV time delay setting.

14.13 Phase Loss / Reverse Test

To test the Phase Loss / Reverse function, a 3-phase voltage source and a timer is needed. 24VDC Auxiliary power is recommended.

Phase Loss/Reverse Test Notes:

- 1) After an Phase Loss/Reverse trip or occurs, repeated Phase Loss trips are blocked until current is re-established, or until the Phase Loss condition goes away, or until the breaker is closed (if a limit switch is present on the breaker).
- 2) If a Phase Loss/Reverse alarm occurs, it is automatically reset when the condition goes away.

Phase Loss Test Procedure:

- 1) For safety, temporarily disconnect the breaker stabs from the VDM fuses.
- 2) Recommended step: Apply 24VDC auxiliary power to the AC-PRO-NW. See Section 3.4 for additional information about 24VDC Auxiliary Power.
- 3) Connect the 3-phase voltage source to the AC-PRO-NW VDM, at the line side of the VDM fuses.
- 4) The voltages should be equal magnitude (120VAC minimum), 120 degrees apart.
- 5) No Phase Loss trip should occur. Correct Line-to-Line voltages should be displayed on the AC-PRO-NW.
- 6) Disconnect one phase voltage by safely pulling the VDM fuse for that phase and start the timer.
NOTE/REMINDER: If primary current is not flowing through the breaker (for CT power), and 24VDC auxiliary power is not applied, this test can only be performed by disconnecting Phase C voltage. (since AC-PRO-NW derives VDM power from Phase A-B voltage).
- 7) A Phase Loss/Reverse trip should occur within +/- 0.25 seconds of the Phase Loss/Reverse time delay setting.

14.14 Reverse Power Test

To test the Reverse Power function, a Relay Test Set and a timer is needed. 24VDC Auxiliary power is recommended.

Reverse Power Test Notes:

- 1) After an Reverse Power trip or occurs, repeated Reverse Power trips are blocked until current is re-established, or until the Reverse Power condition goes away, or until the breaker is closed (if a limit switch is installed for the AC-PRO-NW).
- 2) If a Reverse Power alarm occurs, it is automatically reset when the condition goes away.

Reverse Power Test Procedure:

- 1) For safety, temporarily disconnect the breaker stabs from the VDM fuses.
- 2) Recommended step: Apply 24VDC auxiliary power to the AC-PRO-NW. See Section 3.4 for additional information about 24VDC Auxiliary Power.
- 3) Connect the Relay Test Set to the AC-PRO-NW VDM, at the line side of the VDM fuses.
- 4) Inject current in the primary stabs above pickup.
- 5) A trip should not occur.
- 6) Inject current in the load stabs.
- 7) A Reverse Power trip should occur within +/- 0.25 seconds of the Reverse Power time delay setting.

15.0 Secondary Injection Testing

Although primary injection testing is the recommended and preferred method to test an AC-PRO-NW installation, secondary injection testing can also be used.

15.1 Secondary Injection Test Set

The B-292 secondary injection test set (with blue panel) can test both the original AC-PRO and AC-PRO-NW trip units. Testing the AC-PRO-NW with the B-292 Test Set requires the CA-7-114-NW test cable. See Section 5.4 Test Set connection.

The B-291 secondary injection test set (with red panel) cannot test the AC-PRO-NW trip unit.



Figure 15.1: B-292 Secondary Injection Test Set

15.2 Standard Relay Test Set

Although primary injection is recommended, and use of the URC B-292 test set is recommended as the next alternative, many standard relay test sets can also be used to secondary injection test the AC-PRO-NW trip unit.

The following are required:

- 24VDC Power Supply to power up the AC-PRO-NW trip unit so that it will accept current
Note: 24VDC must be used. (USB power is NOT adequate for this purpose).
- Relay test set with a 0 to 15 Amp range
- True RMS ammeter in the test set or externally connected
- Method to stop the relay test set and test set timer when the breaker trips

Test procedure:

1. Power up the AC-PRO-NW trip unit with 24VDC power so it will accept current.
2. Temporarily turn off GF.
3. Connect the output leads from the relay test set to the front test port. (contact URC for terminal and connector information).
4. Proceed with pick-up and time testing of Phase "A"
5. When finished, similarly test Phase "B" & "C"
6. Turn GF on (if desired) and test by injecting current on any one of the Phases

****** IMPORTANT ******

The CT circuits are internally grounded to the AC-PRO-NW. **If any of the CT wires are externally grounded, the AC-PRO-NW will not read current correctly.**

Some relay test sets have a grounded current output. To secondary injection test the AC-PRO-NW trip unit with this type of test set, the AC-PRO-NW trip unit must be isolated from the test set ground.

15.3 LT Delay Testing Chart

This chart provides trip times in Seconds for the LT delay settings at 1.5X, 2.0X, 3.0X and 6.0X where “X” is in multiples of the LT pick-up setting.

The Time-Current Curves in Figure 18.2 along with the equations in Section 18.1 can be used to determine the trip times of the other trip functions.

The Maximum, Minimum and Nominal trip times are given for each LT delay setting and the three listed test currents.

LT Delay Setting	Trip Time Range	Test Current				LT Delay Setting	Trip Time Range	Test Current				LT Delay Setting	Trip Time Range	Test Current			
		1.5X	2.0X	3.0X	6.0X			1.5X	2.0X	3.0X	6.0X			1.5X	2.0X	3.0X	6.0X
0.5	Max	9.84	5.54	2.46	0.62	8.5	Max	167.28	94.10	41.82	10.46	16.5	Max	324.72	182.66	81.18	20.30
	Nominal	8.00	4.50	2.00	0.50		Nominal	136.00	76.50	34.00	8.50		Nominal	264.00	148.50	66.00	16.50
	Min	6.56	3.69	1.64	0.41		Min	111.52	62.73	27.88	6.97		Min	216.48	121.77	54.12	13.53
1.0	Max	19.68	11.07	4.92	1.23	9.0	Max	177.12	99.63	44.28	11.07	17.0	Max	339.56	188.19	83.64	20.91
	Nominal	16.00	9.00	4.00	1.00		Nominal	144.00	81.00	36.00	9.00		Nominal	272.00	153.00	68.00	17.00
	Min	13.12	7.38	3.28	0.82		Min	118.08	66.42	29.52	7.38		Min	223.04	125.46	55.76	13.94
1.5	Max	29.52	16.61	7.38	1.85	9.5	Max	186.96	105.17	46.74	11.69	17.5	Max	344.40	193.73	86.10	21.53
	Nominal	24.00	13.50	6.00	1.50		Nominal	152.00	85.50	38.00	9.50		Nominal	280.00	157.50	70.00	17.50
	Min	19.68	11.07	4.92	1.23		Min	124.64	70.11	31.16	7.79		Min	229.60	129.15	57.40	14.35
2.0	Max	39.36	22.14	9.84	2.46	10.0	Max	196.80	110.70	49.20	12.30	18.0	Max	354.24	199.26	88.56	22.14
	Nominal	32.00	18.00	8.00	2.00		Nominal	160.00	90.00	40.00	10.00		Nominal	288.00	162.00	72.00	18.00
	Min	26.24	14.76	6.56	1.64		Min	131.20	73.80	32.80	8.20		Min	236.16	132.84	59.04	14.76
2.5	Max	49.20	27.68	12.30	3.08	10.5	Max	206.64	116.24	51.66	12.92	18.5	Max	364.08	204.80	91.02	22.76
	Nominal	40.00	22.50	10.00	2.50		Nominal	168.00	94.50	42.00	10.50		Nominal	296.00	166.50	74.00	18.50
	Min	32.80	18.45	8.20	2.05		Min	137.76	77.49	34.44	8.61		Min	242.72	136.53	60.68	15.17
3.0	Max	59.04	33.21	14.76	3.69	11.0	Max	216.48	121.77	54.12	13.53	19.0	Max	373.92	210.33	93.48	23.37
	Nominal	48.00	27.00	12.00	3.00		Nominal	176.00	99.00	44.00	11.00		Nominal	304.00	171.00	76.00	19.00
	Min	39.36	22.14	9.84	2.46		Min	144.32	81.18	36.08	9.02		Min	249.28	140.22	62.32	15.58
3.5	Max	68.88	38.75	17.22	4.31	11.5	Max	226.32	127.31	56.58	14.15	19.5	Max	383.76	215.87	95.94	23.99
	Nominal	56.00	31.50	14.00	3.50		Nominal	184.00	103.50	46.00	11.50		Nominal	312.00	175.50	78.00	19.50
	Min	45.92	25.83	11.48	2.87		Min	150.88	84.87	37.72	9.43		Min	255.84	143.91	63.96	15.99
4.0	Max	78.72	44.28	19.68	4.92	12.0	Max	236.16	132.84	59.04	14.76	20.0	Max	393.60	221.40	98.40	24.60
	Nominal	64.00	36.00	16.00	4.00		Nominal	192.00	108.00	48.00	12.00		Nominal	320.00	180.00	80.00	20.00
	Min	52.48	29.52	13.12	3.28		Min	157.44	88.56	39.36	9.84		Min	262.40	147.60	65.60	16.40
4.5	Max	88.56	49.82	22.14	5.54	12.5	Max	246.00	138.38	61.50	15.38	20.5	Max	403.44	226.94	100.86	25.22
	Nominal	72.00	40.50	18.00	4.50		Nominal	200.00	112.50	50.00	12.50		Nominal	328.00	184.50	82.00	20.50
	Min	59.04	33.21	14.76	3.69		Min	164.00	92.25	41.00	10.25		Min	268.96	151.29	67.24	16.81
5.0	Max	98.40	55.35	24.60	6.15	13.0	Max	255.84	143.91	63.96	15.99	21.0	Max	413.28	232.47	103.32	25.83
	Nominal	80.00	45.00	20.00	5.00		Nominal	208.00	117.00	52.00	13.00		Nominal	336.00	189.00	84.00	21.00
	Min	65.60	36.90	16.40	4.10		Min	170.56	95.94	42.64	10.66		Min	275.52	154.98	68.88	17.22
5.5	Max	108.24	60.89	27.06	6.77	13.5	Max	265.68	149.45	66.42	16.61	21.5	Max	423.12	238.01	105.78	26.45
	Nominal	88.00	49.50	22.00	5.50		Nominal	216.00	121.50	54.00	13.50		Nominal	344.00	193.50	86.00	21.50
	Min	72.16	40.59	18.04	4.51		Min	177.12	99.63	44.28	11.07		Min	282.08	158.67	70.52	17.63
6.0	Max	118.08	66.42	29.52	7.38	14.0	Max	275.52	154.98	68.88	17.22	22.0	Max	432.96	243.54	108.24	27.06
	Nominal	96.00	54.00	24.00	6.00		Nominal	224.00	126.00	56.00	14.00		Nominal	352.00	198.00	88.00	22.00
	Min	78.72	44.28	19.68	4.92		Min	183.68	103.32	45.92	11.48		Min	288.64	162.36	72.16	18.04
6.5	Max	127.92	71.96	31.98	8.00	14.5	Max	285.36	160.52	71.34	17.84	22.5	Max	442.80	249.08	110.70	27.68
	Nominal	104.00	58.50	26.00	6.50		Nominal	232.00	130.50	58.00	14.50		Nominal	360.00	202.50	90.00	22.50
	Min	85.28	47.97	21.32	5.33		Min	190.24	107.01	47.56	11.89		Min	295.20	166.05	73.80	18.45
7.0	Max	137.76	77.49	34.44	8.61	15.0	Max	295.20	166.05	73.80	18.45	23.0	Max	452.64	254.61	113.16	28.29
	Nominal	112.00	63.00	28.00	7.00		Nominal	240.00	135.00	60.00	15.00		Nominal	368.00	207.00	92.00	23.00
	Min	91.84	51.66	22.96	5.74		Min	196.80	110.70	49.20	12.30		Min	301.76	169.74	75.44	18.86
7.5	Max	147.60	83.03	36.90	9.23	15.5	Max	305.04	171.59	76.26	19.07	23.5	Max	462.48	260.15	115.62	28.91
	Nominal	120.00	67.50	30.00	7.50		Nominal	248.00	139.50	62.00	15.50		Nominal	376.00	211.50	94.00	23.50
	Min	98.40	55.35	24.60	6.15		Min	203.36	114.39	50.84	12.71		Min	308.32	173.43	77.08	19.27
8.0	Max	157.44	88.56	39.36	9.84	16.0	Max	314.88	177.12	78.72	19.68	24.0	Max	472.32	265.68	118.08	29.52
	Nominal	128.00	72.00	32.00	8.00		Nominal	256.00	144.00	64.00	16.00		Nominal	384.00	216.00	96.00	24.00
	Min	104.96	59.04	26.24	6.56		Min	209.92	118.08	52.48	13.12		Min	314.88	177.12	78.72	19.68

Table 15-A: Long Time Delay Test Chart

15.4 Neutral Protection Testing Chart

The LT chart in previous section can also be used for NP Long Time testing. NP ST and INST will follow the time-current curves multiplied by a pickup percentage.

16.0 Ratings & Physical Information

Ambient Temperature:

Trip Unit:

-4°F (-20°C) to 149°F (65°C)

OLED Display:

-22°F (-30°C) to 185°F (85°C)

Battery:

-40°F (-40°C) to 158°F (70°C)

Humidity:

95% non-condensing

Conformal Coating (on circuit boards):

Acrylic conformal coating,

HumiSeal type 1A33

Contamination resistant membrane keypad

17.0 Warranty

A conditional 2-year warranty is offered with each AC-PRO-NW trip unit.

Contact Utility Relay Company for full details.

18.0 Time-Current Curves (TCC)

The TCCs are shown in Figures 18.1, 18.2, 18.3 and 18.4.

AC-PRO-NW TCCs are very similar to the OEM trip unit TCCs and also similar to the AC-PRO-II TCCs.

The curves are shown on log-log graph with seconds in the vertical direction and current in the horizontal direction.

Overload and fault currents are shown as multiples of the LT pick-up setting. GF current is shown as a percentage of the CT rating.

Tolerances for the Pick-Up bands are $\pm 10\%$ (or $\pm 10A$, whichever is greater) in the current direction. Tolerance for LT, ST $I^2 T$ and GF $I^2 T$ trip times are $+23\%$ and -17% in the time direction. Tolerance for GF $I^2 T$ trip times are $+69\%$ and -38% in the time direction.

Instantaneous pick-up tolerance is $\pm 10\%$ for 1A CTs. For primary injection, see below.

Primary Injection Instantaneous pick-up tolerance: -20% to $+10\%$. AC-PRO-NW Instantaneous protection utilizes fast analog peak detection. Most Primary Injection test sets display RMS current. Due to possible asymmetry (offset) in primary test set output, and possible CT remanence associated with primary injection testing, the minus (-) tolerance is extended to -20% for primary injection testing only.

The curves for the following time bands:
 Long Time (LT)
 Short Time (ST) with $I^2 T$ ON
 Ground Fault (GF) with $I^2 T$ ON

are based on the following equation:

$$I^2 T = \text{Constant}$$

Where: I is current in amps
 T is time to trip in seconds (center of the band)

When performing trip-timing tests using a primary injection test set, the trip time at various test currents can be determined by calculation as explained in Sections 18.1, 18.2, 18.3 and 18.4.

The TCCs are based on a total actuator operating time plus breaker opening time in the 16ms to 33ms range.

18.1 Long Time (LT) Trip Time

For overload currents, the " $I^2 T = \text{Constant}$ " equation can be restated as follows:

$$T = \frac{TBC_{LT}}{X^2}$$

Where: T = time to trip in seconds (center of the band)
 X = current in multiples of the LT pick-up setting
 TBC_{LT} = the LT Time Band Constant
 = $36 \times$ LT time band setting

**** NOTE ****

The LT Time Band Constant (TBC_{LT}) is by definition 36 times the LT Time Band Setting in seconds.

EXAMPLE #1:

CT Rating 1600A
 LT pick-up 1200A
 LT time band 20.0S
 Overload Current 3600A

$$\begin{aligned} TBC_{LT} &= 36 \times \text{LT Time Band Setting} \\ &= 36 \times 20.0 \\ &= 720 \end{aligned}$$

$$\text{and } X = \frac{\text{overload current}}{\text{LT Pick-Up}} = \frac{3600A}{1200A} = 3$$

therefore:
 trip time = $T = \frac{TBC_{LT}}{X^2}$ or $\frac{720}{3^2} = \frac{720}{9}$
 = 80 seconds

**** IN SUMMARY ****

To calculate the LT trip time:

- 1) Calculate the LT Time Band Constant (TBC_{LT})
- 2) Calculate "X" where

$$X = \frac{\text{overload current}}{\text{LT Pick-Up Setting}}$$
- 3) Solve the equation:

$$\text{trip time(sec)} = \frac{TBC_{LT}}{X^2}$$

18.2 Short Time (ST) Trip Time

With $I^2 T$ off or for currents greater than $10 \times$ LT pick-up setting, the ST trip time is a constant equal to the ST time band setting.

With $I^2 T$ on and for currents less than $10 \times$ LT pick-up setting, the ST trip time is determined by the following equation:

$$T = \frac{TBC_{ST}}{X^2}$$

Where: T = time to trip in seconds (center of the band)
 X = current in multiples of the LT pick-up
 TBC_{ST} = the ST Time Band Constant

**** NOTE ****

The ST Time Band Constant (TBC_{ST}) =
 40 for the .40S Time Band
 30 for the .30S Time Band
 20 for the .20S Time Band
 15 for the .15S Time Band
 10 for the .10S Time Band
 7 for the .07S Time Band
 2 for the .00S Time Band

EXAMPLE #2:

CT Rating 1600A
 LT pick-up 1200A
 ST pick-up 6000A
 ST delay .20S I²T ON
 Overload Current 7200A

$$TBC_{ST} = 20$$

$$\text{and } X = \frac{\text{overload current}}{\text{LT Pick-Up}} = \frac{7200A}{1200A} = 6$$

therefore:

$$\begin{aligned} \text{trip time} = T &= \frac{TBC_{ST}}{X^2} \text{ or } \frac{20}{6^2} = \frac{20}{36} \\ &= .556 \text{ seconds} \end{aligned}$$

****** IN SUMMARY ******

To calculate the ST I²T trip time:

- 1) Determine the ST Time Band Constant (TBC_{ST})
- 2) Calculate "X" where

$$X = \frac{\text{overload current}}{\text{LT Pick-Up}}$$
- 3) Solve the equation:

$$\text{trip time(sec)} = \frac{TBC_{ST}}{X^2}$$

18.3 Ground Fault (GF) Trip Time

With the GF slope set to OFF, the GF trip time is a constant equal to the GF Time Band setting.

With the GF slope set to I²T:

For GF currents greater than 0.6 times the CT rating, the GF trip time is a constant equal to the GF Time Band setting.

For GF currents less than 0.6 times the CT rating, the GF trip time is determined by the equations below.

With the GF slope set to I⁵T:

For GF currents greater than 4.0 times the GF Pickup, the GF trip time is a constant equal to the GF Time Band setting.

For GF currents less than 4.0 times the GF Pickup, the GF trip time is determined by the equations below:

$$T = \frac{TB2C_{GF}}{X_{GF}^2} \text{ for } I^2T \quad \text{OR} \quad T = \frac{TB5C_{GF}}{X5_{GF}^5} \text{ for } I^5T$$

Where: T = time to trip in seconds (center of the band)

$$X_{GF} = \frac{\text{ground fault current}}{\text{CT rating}}$$

$$X5_{GF} = \frac{\text{ground fault current}}{\text{GF Pickup}}$$

TB2C_{GF} = the GF I²T Time Band Constant

TB5C_{GF} = the GF I⁵T Time Band Constant

****** NOTE ******

The GF I²T Time Band Constant (TB2C_{GF}) =
 0.5 for the .50S Time Band
 0.4 for the .40S Time Band
 0.3 for the .30S Time Band
 0.2 for the .20S Time Band
 0.1 for the .10S Time Band
 0.05 for the .00S Time Band

****** NOTE ******

The GF I⁵T Time Band Constant (TB5C_{GF}) =
 512 for the .50S Time Band
 409.6 for the .40S Time Band
 307.2 for the .30S Time Band

204.8 for the .20S Time Band
 102.4 for the .10S Time Band
 51.2 for the .00S Time Band

EXAMPLE #3 (I²T Slope):

CT Rating 1600A
 LT pick-up 1200A
 GF pick-up 640A
 GF time band .20S I²T Slope
 Ground Fault Current 800A

$$TB2C_{GF} = 0.072$$

$$\text{and } X_{GF} = \frac{\text{ground fault current}}{\text{CT Rating}} = \frac{800A}{1600A} = 0.5$$

therefore:

$$\begin{aligned} \text{trip time} = T &= \frac{TB2C_{GF}}{X_{GF}^2} \text{ or } \frac{0.072}{(0.5)^2} = \frac{0.072}{0.25} \\ &= 0.8 \text{ sec} \end{aligned}$$

****** IN SUMMARY ******

To calculate the GF I²T trip time:

- 1) Determine the GF Time Band Constant (TB2C_{GF})
- 2) Calculate "X_{GF}" where

$$X_{GF} = \frac{\text{ground fault current}}{\text{CT Rating}}$$
- 3) Solve the equation:

$$\text{trip time(sec)} = \frac{TB2C_{GF}}{X_{GF}^2}$$

EXAMPLE #4 (I⁵T Slope):

CT Rating 2000A
 LT pick-up 2000A
 GF pick-up 800A
 GF time band .30S I⁵T Slope
 Ground Fault Current 2400A

$$TB5C_{GF} = 307.2$$

$$\text{and } X5_{GF} = \frac{\text{ground fault current}}{\text{GF Pickup}} = \frac{2400A}{800A} = 3.0$$

therefore:

$$\begin{aligned} \text{trip time} = T &= \frac{TB5C_{GF}}{X5_{GF}^5} \text{ or } \frac{307.2}{(3.0)^5} = \frac{307.2}{243} \\ &= 1.264 \text{ sec} \end{aligned}$$




Figure 18.1: Overload TCC

18.4 Phase Current U/B Trip Time

Phase Current Unbalance is calculated as follows:

$$U/B = \frac{(I_{NL} - I_{NS}) \times 100\%}{I_{NL}}$$

Where:

I_{NL} = Largest Phase current

I_{NS} = Smallest Phase current

The Phase Unbalance function is defeated if any two phase currents are less than 10% of the CT rating.

The tolerance for the Phase Unbalance Pick-Up is ± 10 percentage points. A Phase Current Unbalance Pick-Up of 20% would have a tolerance of 10% to 30% unbalance. An Phase Unbalance Pick-Up of 50% would have a tolerance of 40% to 60% unbalance.

The Phase Current Unbalance trip time is a definite time as shown on the U/B TCC in Figure 18.5

The tolerance for the U/B trip time is $\pm 10\%$ of the setting.

****** NOTE ******

The U/B function should not be confused with the GF function.

The U/B function is a motor protection function and should ONLY be used on breakers feeding a large 3-phase motor where currents are normally balanced.

EXAMPLE #5 (Phase Current U/B):

CT Rating	800A
LT Pickup	600A
Motor FLC	429A
Motor Start Time	22 Sec
Unbalance Pickup set to protect windings from negative sequence currents due to unbalance	
U/B pick-up	35%

U/B is $0.35 \times 429A$ or 150A difference between phases.

Unbalance delay set to ride thru motor starting time:
U/B time delay 30 Sec > 22 Sec is adequate

18.5 Neutral Protection (NP) Trip Times


The NP LSI tripping times are calculated in the same manner as the Overload LSI curves multiplied by a Percentage of Pickup. Range is 50% to 200%.

EXAMPLE #6 (Neutral Protection NP):

CT Rating	1600A
LT Pickup	1400A
ST Pickup	2400A
INST Pickup	7200A

Neutral Protection (NP): Set at 50% as neutral is only rated for half the Phase Conductors.


NP-LT	$1400A \times .50 = 700A$
NPT-ST	$2400A \times .50 = 1200A$
NP-INST	$7200A \times .50 = 3600A$



AC-PRO-NW G.F. Rev 1.0 01/21/2023

Figure 18.2: Ground Fault (GF) TCC

AC-PRO-NW Trip Unit



AC-PRO-NW Q.T. Rev 1.0 02/27/2023

Figure 18.3: QUICK-TRIP Ground Fault and QUICK-TRIP Instantaneous TCCs




Figure 18.4: Phase Current Unbalance TCC

18.6 Current Metering Accuracy

For 1-Amp secondary CTs:
+/- 2% (or +/- 10A, whichever is greater) for currents between 20% and 150% of CT Rating

19.0 Voltage & Power Calculations

Voltage accuracy:
+/- 1.5% for 80V to 600V.

Power accuracy (Instantaneous values)
+/- 5% for currents between 10% and 150% of CT rating

Energy calculations: Refer to Section 13.0.

20.0 Error and Alarms

20.1 Internal Error

If an internal error occurs in the AC-PRO-NW, the OK LED will not be lit and the screen below will appear. (*The OK LED flashes if trip unit is fully functional.*)



Figure 20.1: Internal Error Screen

If this screen appears and persists, please contact URC.

If configured in user settings, the programmable relay will operate for this condition. The "Exit" button is available and allows bypassing this screen for temporary menu navigation. If the condition is still present, this screen will re-appear the next time the display is turned on.

20.2 Actuator Open Circuit

If the AC-PRO-NW detects an open circuit at the actuator terminals, the OK led will not be ON and the following screen will appear, indicating an actuator open circuit condition, in which case the trip unit will not trip the breaker. Repair the actuator connection.



Figure 20.2: Actuator Open screen

If configured in user settings, the programmable relay will operate for this condition.

The "Exit" button allows bypassing this screen for temporary menu navigation. If the condition is still present, this screen will appear the next time the display is turned on.

20.3 CT Open Circuit

If configured in user settings, if the AC-PRO-NW detects an open CT circuit, the OK led will stop flashing and a "CT Open Circuit" screen will appear. Repair the CT connection.

If configured in user settings, the programmable relay will operate for this condition.

The "Exit" button allows bypassing this screen for temporary menu navigation. If the condition is still present, this screen will appear the next time the display is turned on.

20.4 Alarm Screens

If configured in user settings, the programmable relay will operate when a Trip Alarm, OV Alarm, UV Alarm, Phase Loss Alarm, or Ground Fault Alarm occurs and an "Alarm" screen will appear.

NOTE: the Programmable Relay will only operate for Alarms if the Programmable Relay setting is set to "Alarm". The word "Relay" will only appear in the screens below if the Programmable Relay setting is set to "Alarm".




Figure 20.3: Alarm Screen (example shown is Trip Alarm)




Figure 20.4: Clear Alarms Screen

Pressing the "View" button will show the trip history information. Pressing the "Clear" button will show the clear alarm screen. Pressing "Exit" will temporarily bypass this screen for temporary menu navigation. If the condition is still present, this screen will appear the next time the display is turned on.

Refer to Section 5.5.1 and Table 5-A.

20.5 Un-Calibrated

If the following screen appears, do not place the trip unit in service. Please contact URC.




Figure 20.5: Un-Calibrated Screen

21.0 Battery

21.1 Checking the Battery Voltage

See Section 6.4.2.

21.2 Battery Replacement

For best performance, replace the battery with the following 3-volt lithium battery:

Panasonic CR2 Industrial Lithium battery 3V
#CR15H270

A replacement battery can be purchased from:

- Utility Relay Co. Part # T-125
- Digi-Key Part # P157-ND
www.digikey.com
- Newark Part #15R3550
www.newark.com

Lithium battery ratings:

- 850 mAh Capacity



Figure 21.1: Battery Cover/Holder

To replace the battery:

- The breaker must be out of service and de-energized for safety.
- Loosen the two battery cover screws with T 10x50 screwdriver.
- The CR2, 3V Lithium Battery is inserted to the back of the battery cover/holder.
- Remove the old battery and install new battery with the positive (+) nub end of the battery mounted to the left.
- Replace Battery Cover / holder door and screws.
- If applicable, to reset low battery state, perform manual battery test using the MORE Menu.

**** IMPORTANT ****

For best performance, replace the battery with the recommended Panasonic CR2 3-volt lithium battery.

The breaker must be removed from service before replacing the battery.

The replacement battery must be inserted with the proper polarity.

After replacing battery, Time and Date must be set. See Section 6.4.1.

22.0 InfoPro-AC™ Software Application

InfoPro-AC is a software application that can be used with AC-PRO-NW for the following:

- Settings – upload, download, view, save, and print.
- Trip history including waveforms – view, save, and print.
- Waveforms (on-demand) – view, save, and print.
- Current, voltage, & power readings – view.
- Alarms and trip unit status Information
- Trip unit info: serial number, firmware versions, breaker name.
- Firmware updates
- Time-Current curves and Test Reports
- Breaker Control (Trip) and Close (E/O)
- QUICK-TRIP® ON/OFF Control

Recommended Operating System:
Microsoft Windows 10 or 11.

Connection:
mini-USB (cable not included)

The InfoPro-AC™ software application is available for download at:
http://www.utilityrelay.com/Side_Bar/Downloads.html



Open the downloaded file and follow the instructions to install the application.

****** IMPORTANT ******

InfoPro-AC needs the correct USB device driver to communicate with AC-PRO-NW. Microsoft Windows often already includes these drivers. However, if this driver is not already installed:

- 1) Ensure your PC is connected to the Internet.
- 2) Connect AC-PRO-NW to your PC with the USB cable.
- 3) Automatic driver update process:
 - a) After you connect the AC-PRO-NW, if you have an internet connection and administrative rights on your PC, Microsoft Windows should install the driver automatically after a few minutes.
- 4) Manual driver update process:
 - a) Open Windows Device Manager
 - b) Right click on the AC-PRO-NW device. It will be located under Ports or under Other Devices.
 - c) Choose the "Update Driver Software" option.
 - d) Choose the "Search automatically" option.
 - e) After the driver is installed, close and then reopen the InfoPro-AC Application.

NOTE: Any pending Microsoft Windows updates can interfere with the driver installation process.

For more detailed instructions with screenshots, contact URC.

Refer to the InfoPro-AC™ Help Guide within the InfoPro—AC application for specific information and instructions.

22.1 Firmware Versions and Updates

To determine which firmware version is currently installed on your AC-PRO-NW, use the MORE menu.
See Figure 6.5: MORE Menu.

The InfoPro-AC application can be used to update AC-PRO-NW firmware in the field using the USB port. AC-PRO-NW Firmware update instructions can be found in the InfoPro-AC Help Menu. For firmware version information see the following link:

http://www.utilityrelay.com/Side_Bar/Firmware_versions.html






Figure 22.1: InfoPro-AC Readings Tab




Figure 22.2: InfoPro-AC Waveform Tab




Figure 22.3: InfoPro-AC Trip History Tab




Figure 22.4: InfoPro-AC Settings Tab






Figure 22.5: InfoPro-AC TCC / Tests Tab



Breaker Closed, Quick-Trip ON



Breaker Open, Quick-Trip OFF

Figure 22.6: InfoPro-AC Breaker Control Window

23.0 RS-485 Communications

23.1 RS-485 Communications Introduction

Creating a complete power monitoring and communications system for a low voltage power distribution system is easy with Utility Relay Company's AC-PRO-NW. The standard AC-PRO-NW trip unit communicates using industry standard Modbus RTU protocol through a single shielded twisted pair wire connected to the RS485 port. A number of trip units can be daisy-chained together to simplify installation.

AC-PRO-NW communications features and information:

- Currents, 3-phase ($\pm 2\%$ accuracy for currents between 20% and 150% of the CT rating)
- Review and change all settings ("Changing settings over Comm" user setting must be enabled at trip unit).
- Voltages, 3-phase
- KW, 3-phase & total ($\pm 5\%$ accuracy for currents between 10% and 150% of the CT rating)
- KWHr, total
- KVA, 3-phase & total
- KVAHr, total
- KWD, KVAD
- Power Factor data
- Breaker position status (open or closed)
- Trip unit alarms and status information
- Sluggish-Breaker indication
- QUICK-TRIP ON /OFF status
- Trip history data for the last 8 trips
 - Trip counts
 - Trip type (reason for trip)
 - Trip dates & timestamps
 - Trip currents & voltages
 - Breaker mechanism times
- Trip unit time and date
- Trip unit Information: serial number, firmware revision.
- Forced trip ("Forced trip over Comm" user setting must be enabled at trip unit).

NOTE: Voltage Divider Module (VDM) is required for voltage and power information.

A host PC running HMI software with Modbus device drivers collects information from the trip units. The driver interrogates each trip unit individually and reports that information back to the host PC applications on a continual basis. Additional trip units can be added to the system by simply providing the new trip unit's ADDRESS to the HMI software.

AC-PRO-NW trip units are compatible with the Modbus RTU communication protocol supplied with most HMI systems such as Inductive Automation's Ignition, Siemens WinPM; Wonderware's *InTouch*™, *Intellution*™; Schneider *PowerLogic SMS-3000*™, *ION Enterprise*™, and PME (Power Monitor Expert); Eaton Power Xpert; GE EnerVista; and Power Measurements *PEGASYS*™.

23.2 Communications Components

An AC-PRO-NW Modbus Communications system consists of the following hardware components:

1. AC-PRO-NW trip unit and breaker retrofit components.
2. Host PC (supplied by others).
3. Cabling topology (supplied by others).

Additional components to consider include:

1. OPC software with Modbus device drivers (supplied by others).
2. Modbus RTU/Ethernet converter (supplied by others).
3. Human-Machine Interface (HMI) System (supplied by others) or Smart 1-Line (HMI) supplied by URC (See Section 23.4.2). These systems are used to view trip

unit information graphically and often contain their own compatible Modbus Driver.

23.3 Communications Wiring

Although all AC-PRO-NW trip units are capable of communications, units that are specifically ordered for communications are furnished with quick-disconnect communications cable assemblies. The cable assembly features a heavy-duty twist-lock connector and a terminal block, which mounts inside the switchgear.

The purpose of the terminal block is to provide a connection location for the twisted pair wire as it is daisy-chained from cell to cell in a switchgear lineup. This enables any individual communicating AC-PRO-NW (mounted on a circuit breaker) to be removed without disrupting communications between the other communicating AC-PRO-NW trip units.

See Figure 5. for wiring diagram. If replacing an existing AC-PRO with AC-PRO-NW, remove the existing 2-piece AC-PRO communications cable from the cubicle, and use the new 2-piece cable shipped with the AC-PRO-NW.

****IMPORTANT****

Do NOT use external termination resistors or circuits with AC-PRO-NW.

23.4 System Components & Computer Hardware

URC trip units communicate over the RS485 interface at 9600, 19200, 38400, 57600 or 115200 Baud, with 8 data bits, 1 stop bit and no parity using the Modbus RTU communications protocol.

23.4.1 Ethernet

With the addition of an RS485 to Ethernet Converter an existing Local Area Network (LAN) can be used to carry data between trip units and the PC. Converters are widely available from a variety of industrial computer manufacturers.

RS485 to Ethernet Converters are designed to be compatible with a TCP/IP network environment and typically connect to a LAN using standard 10Base-T modular CAT-5 cabling. These converters offer a relatively inexpensive means of connecting to a LAN. (See Figure 23.1: Typical Communications Configuration Example).

23.4.2 Smart 1-Line

The Smart 1-Line is a field-configurable electronic 1-Line diagram with real-time data obtained via Modbus communications, allowing you to determine LV substation status at a glance. The Smart-1-Line can display currents, voltages, power, frequency, energy, trip-unit settings, waveforms, alarms, breaker open/close status along with remote tripping of breakers, and much more. It ships with software already installed, ready for connecting to your AC-PRO-NW Modbus Communications network, with minimal basic setup required. (See Figure 23.2: Smart 1-Line Communication Solution).

23.5 Modbus Registers

The AC-PRO-NW Modbus Register Map is available for download at the following location: :

[Modbus Communication](#)






Figure 23.1: Typical Communications Configuration Example




Figure 23.2: Smart 1-Line Communication Solution

Smart 1-Line™ Run Mode Example




Figure 23.3: Smart 1-Line / Run Mode Example

Smart 1-Line™

Some of the information that can be displayed in the electronic 1-Line diagram:

- Currents
- Voltage, Power, Energy
- Breaker status
- Breaker and load ID/name
- Alarms
- Quick-Trip Status




Figure 23.4: Smart 1-Line / Breaker Status and Alarms Screen

24.0 Breaker Trip and Close Control

The AC-PRO-NW is capable of initiating a manual Trip and manual Close command, including a user-set time delay if the command is initiated by the user at the front panel. This time delay allows the user to safely move away from the breaker before it operates.

The Trip command trips the breaker via a signal to the trip actuator. The breaker must be closed and the AC-Pro-NW must be powered by CTs, VDM, USB, or 24VDC Aux power for the Trip command to be available. In addition the Actuator circuit must be complete (not open) for the command to be available.

For these trips, trip data is recorded, including date/time, RMS values, and breaker mechanism time. These trips are logged as "Safe-T-Trip" trip type.

The Close command sends a signal to the existing breaker close coil. To execute a successful close operation, the breaker must be equipped with a close coil, must have close control voltage present, and the close circuit must be wired properly through the trip unit. In addition, the breaker must be open and the AC-PRO-NW Close Breaker user setting must be ON for the Close command to be available.


The Trip and Close commands can be initiated on the front panel, via USB communications, via Wireless communications, or via RS-485 Modbus communications.

Below are the trip unit screens for Breaker Control: When at the "Main Screen", press the **Display** push button to access additional smart button options




Press "Cont"

Trip and Close buttons will appear based on Breaker position and whether the "Close breaker" user setting is set to "ON"



Set delay, and select Trip or Close




Enter last 4 of serial number.

If Trip was selected.....



Or, if Close was selected.....



The countdown timer is displayed on the screen, allowing the operator to move safely away from the breaker before it operates.



25.0 Wireless Communications

The AC-PRO-NW is capable of Wireless communications with a Windows PC with a URC Wireless dongle and URC InfoPro-AC software application.

When the connection is established and authenticated, InfoPro-AC software is capable of all functions (same functions as USB cable connection).

For wireless communication to be active, the Wireless (circuitry) switch on the back of the unit must be ON, and the user must enable wireless communication using the front screen and buttons.

Establishing a wireless connection is a secure process, including generation and entry of unique 6-digit PIN. The unique PIN is randomly generated each time per industry standard security methods. In addition, in the process of enabling the wireless feature, the user sets a “**Timeout**” (idle timeout) setting each time a wireless session is started. The idle timer starts when communication is not occurring. The idle timer is reset when communication occurs. If the timer reaches the user set “timeout”, the radio will be disabled (Mode switches to OFF).

The **wireless (circuitry) switch on the back** of the AC-PRO-NW allows the wireless radio circuitry to be switched “ON” or “OFF”. The switch is not accessible after the AC-PRO-NW is installed.

When the switch is in the “ON” position, it simply means the feature is capable of being turned ON by the user: The radio is “OFF”, unless the user enables the feature using the front screen and buttons. (when the radio is actually ON, the (blue) Wireless LED will flash).

When the switch in the “OFF” position: The radio circuitry is disabled and the feature is not accessible using the front screen and buttons.

URC recommends installing the AC-PRO-NW with the wireless switch “ON”, unless the facility does not permit such features.

The **Wireless (blue) LED** flashes “fast” (multiple flashes per second) when the unit is “advertising” or “pairing”. This occurs when the radio is on, but the AC-PRO-NW is not yet connected to anything, or was disconnected. The LED flashes “slow” (about 0.5 sec ON, 0.5 sec OFF) when a secure connection is established.

A **USB Wireless dongle** is available from URC. This device can be used to allow a Windows PC to wirelessly communicate with AC-PRO-NW.



**USB Wireless dongle
(available from URC)**

Wireless security notes:

The AC-PRO-NW is designed for “Secured Connection Only Mode” (“Secure Mode 1” with “Security Level 4”) meaning all incoming and outgoing traffic involves authenticated connections and encryption. Any device trying to connect that doesn’t support secure connections is disconnected.


Presently, pairing is required every time a connection is established. The user must be at the trip unit to view the PIN.

Wireless communications will cease (Mode will automatically switch to OFF) if URC communications does not occur for a certain period of time (idle timeout – described elsewhere in this section). In addition, there are several means of disconnecting and/or disabling wireless communications as described elsewhere in this Section.

The next page includes instructions for establishing a wireless connection with AC-PRO-NW.

AC-PRO-NW Wireless connection Instructions:


1. Prior to visiting the breaker location, install InfoPro-AC version 5.0.8.0 or later on your PC. www.utilityrelay.com/downloads
2. Ensure your AC-PRO-NW is powered by a permanent power source (24VDC Aux, VDM, or CTs).
3. When at the “Main Screen”, press the display push button to access additional smart button options.



4. Press “BT” (Wireless)




5. Press “Set” and Enter Security Code (last 4 of serial number):




6. Press “On” and then Enter.



7. Set the Idle Timeout delay using the Up & Down buttons. The idle Timeout can be set between 5 – 60 minutes, in 1-minute steps.



8. After pressing Enter, the following screen appears and the Wireless (blue) LED flashes fast, indicating it is in “advertising/pairing” mode.



9. Ensure URC USB Wireless dongle is plugged into a USB port on your Windows PC.
10. Open InfoPro-AC software.
11. Ensure you are near the trip unit. The steps below will require viewing the trip unit screen and time will be limited for security reasons.
12. Select “Wireless” from the Device Menu. A list of available (“advertising”) trip units will be displayed.
13. Select the trip unit you want to connect to.
14. The trip unit will receive the connection request and will display a 6-digit PIN, which will be active for 30 seconds.
15. Enter the PIN into the prompt window in InfoPro-AC software.
16. The trip unit should display “Connected”. The wireless (blue) LED should now flash “slowly”. InfoPro software should now communicate with the trip unit and display its information.
17. The connection can be terminated by several means: browsing to the Wireless Comm screen and changing the Mode to OFF, or closing InfoPro-AC software, or removing the USB dongle, or walking away (move device out of range) and allowing the idle timeout to occur and automatically switch the Mode to OFF.

UTILITYRELAY.COM



I-AC-PRO-NW

URC Utility Relay Company

10100 QUEENS WAY
CHAGRIN FALLS, OH 44024
USA
888.289.2864