
## Utility Relay Company

888-289-2864

AC-PRO-MP<sup>TR</sup> Trip Unit

with STR-58U setting



Ic1 & Ic2 (Relays R1 & R2) Time Current Curve

Figure 10 AC-PRO-MP<sup>™</sup> STR-58U Load Monitoring Time-Current-Curve