


## ZERO-Hertz DC Trip Unit Overload Time Current Curve



ZERO-Hertz<sup>®</sup> DC Trip Unit Overload Time-Current-Curve